Thermo Scientific Orion Star A214 Benchtop and Star A324 Portable pH/ISE Meters

Reference Guide





Ross and the COIL trade dress are trademarks of Thermo Fisher Scientific, Inc. and its subsidiaries.

AQUAfast, AQUASensors, BOD AutoEZ, ionplus, KNIpHE, LogR, No Cal, ORION, perpHect, PerpHecT, pHISA, pHuture, Pure Water, Sage, ROSS, ROSS Ultra, Sure-Flow, Titrator PLUS, and TURBO2 are registered trademarks of Thermo Fisher Scientific, Inc. and its subsidiaries.

A+, All in One, Aplus, AUTO-BAR, AUTO-CAL, Auto-ID, AUTO-READ, AUTO-STIR, Auto-Test, AutoTration, CISA, digital LogR, DuraProbe, EZ Startup, ISEasy, Low Maintenance Triode, Minimum Stir Requirement, MSR, NISS, Optimum Results, Orion Dual Star, Orion Star, SAOB, SMART AVERAGING, SMART STABILITY, Star LogR, Star Navigator 21, Stat Face, Triode are trademarks of Thermo Fisher Scientific, Inc. and its subsidiaries.

Guaranteed Success and The Technical Edge are service marks of Thermo Fisher Scientific, Inc. and its subsidiaries.

© 2011 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific, Inc. and its subsidiaries.

The specifications, descriptions, drawings, ordering information and part numbers within this document are subject to change without notice.

This publication supersedes all previous publications on this subject.

Thermo Scientific Orion Star A214 Benchtop and Star A324 Portable pH/ISE Meters

Chapter 1	Introduction
Chapter 2	Meter Overview
	Meter Connections and Inputs3
	Power Source
	Electrodes and Other Connections
	Connecting Electrode Arm to the Benchtop Meter
	Meter Display
	Meter Keypad
	Meter Maintenance
Chapter 3	Meter Setup
	Navigating the Setup Menu9
	Setup Menu Overview
	pH/ISE Channel Menu
	Settings Menu
	View Log Menu
	Diagnostics Menu
Chapter 4	pH, RmV and ORP Calibration15
	pH Calibration
	Calibration Editing
	RmV Calibration
	ORP Calibration
Chapter 5	ISE Calibration
	ISE Calibration
Chapter 6	Temperature Calibration
Chapter 7	Measurement
Chapter 8	Methods
	Saving the Current Meter Settings as a New Method
	Loading an Existing Method
	Editing, Copying or Deleting an Existing Method

Chapter 9	Data Storage and Retrieval		
	Data Storage Settings	. 27	
	Read Type Selection	.27	
	Computer and Printer Export Settings	.28	
	Data Log Settings	.28	
	Viewing the Calibration Log and Data Log	29	
	Viewing the Calibration Log	.29	
	Viewing the Data Log	.29	
	Exporting the Data Log to a Computer or Printer	30	
	Clearing the Data Log.	. 31	
	Interfacing a Printer	. 32	
	Interfacing a Computer	32	
Chapter 10	Customer Services	. 33	
-	Meter Errors and Recommended Actions	33	
	Meter Self Test and Checkout	34	
	Meter Self Test	.34	
	Meter Checkout (pH)	.34	
	Electrode Stability Test	. 35	
	Meter Factory Reset	35	
	Meter User Reset	36	
	About Meter	. 36	
	Assistance	. 36	
	Warranty and Kegistration	30	
		. 37	
Chapter 11	Meter Compliance	41	
	Notice of Compliance	. 41	
	WEEE Compliance	. 41	
	Declaration of Conformity	42	
	Meter Specifications	43	
Appendix 1	Advanced Meter Features	. 45	
	Automatic pH Buffer Recognition Feature	. 45	
	Testing a pH Electrode for Automatic Buffer Recoanition	.45	
	Electrode Condition Icon	. 46	
	Multipoint Calibration Curve Feature	47	
	Automatic Blank (Non-linear) Correction Feature	48	

This page intentionally left blank.

Chapter 1 Introduction

Thank you for your purchase of the Orion Star A214 benchtop pH/ISE meter or Star A324 portable pH/ISE meter. These meters are capable of measuring pH, mV, relative mV (RmV), ORP, ISE and temperature in °C or °F.

The Orion Star A214 benchtop pH/ISE meters feature

- pH range of -2.000 to 20.000 pH units with 0.1, 0.01 or 0.001 resolution and up to 5 calibration points
- mV, relative mV and ORP range of -2000.0 to +2000.0 mV with 0.1 mV resolution
- ISE range of 0 to 19999 with up to three significant figure resolution and up to five calibration points
- AUTO-READ, continuous (with hold option) and timed measurement modes
- calibration editing
- 2000 point data log
- manual, ready (AUTO-READ) and timed data logging functions
- IP54-rated dust and splash resistant housing

The Orion Star A324 portable pH/ISE meters feature

- pH range of -2.000 to 20.000 pH units with 0.1, 0.01 or 0.001 resolution and up to 5 calibration points
- mV, relative mV and ORP range of -2000.0 to +2000.0 mV with 0.1 mV resolution
- ISE range of 0 to 19999 with up to three significant figure resolution and up to five calibration points
- AUTO-READ, continuous (with hold option) and timed measurement modes
- calibration editing
- 5000 point data log
- manual, ready (AUTO-READ) and timed data logging functions
- IP67-rated dust-proof and waterproof housing

Please read this reference guide thoroughly. Any use outside of these instructions may invalidate your warranty and cause permanent damage to the meter.

This page intentionally left blank.

Chapter 2 Meter Overview

Meter Connections and Inputs

Power Source

- 1. Power adapter (included with benchtop meters, sold separately for portable meters)
 - a. Select the appropriate wall socket plug plate.
 - b. Slide off the clear plastic cover from the plug plate.
 - c. Slide the plug plate into the groove on the back of the power adapter.
 - d. Connect the power adapter to the meter and power outlet.
- 2. Batteries (included with portable meters, sold separately for benchtop meters)
 - a. Select four AA alkaline batteries.
 - b. Confirm that the meter is powered off.
 - c. Remove the battery compartment cover.
 - i. Benchtop meters push down on the battery compartment tab and lift the battery cover up.
 - ii. Portable meters loosen the screws holding the battery cover, release the top portion of the battery cover from the meter (use a coin or your finger) and release the bottom portion of the battery cover.
 - d. Orientate the batteries as shown in the battery compartment housing and insert batteries.
 - e. Replace the battery compartment cover. For portable meters replace the screws.





Electrodes and Other Connections

- 1. Prepare the pH electrode, ion selective electrode (ISE) and any other applicable electrodes according to the directions in the electrode user guide.
- 2. Connect the appropriate items as labeled on the meter and as shown in the figure below:



Star A214 Meter Back Panel



- BNC Input for pH electrode, ion selective electrode (ISE) or ORP/redox electrode with BNC or waterproof BNC connector.
- REF Input for reference electrode with standard 2.5 mm pin-tip connector.
- ATC/CON Input for ATC probe with 8 pin MiniDIN connector.
- Ground Input for a ground wire with a standard pin-tip connector. Orion Star A214 benchtop meters only.
- Power Input for the power adapter.
- Stirrer Input for the stirrer probe, Cat. No. 096019. Orion Star A214 benchtop meters only.
- USB Input for the USB cable, used to connect the meter to a printer or computer.
- RS232 Input for the RS232 cable, used to connect the meter to a printer or computer.

Connecting Electrode Arm to an Orion Star A Series Benchtop Meter



Orion Star A series benchtop meters include an electrode arm that can be attached to either side of the meter.

- 1. Unpack the electrode arm and base.
- 2. Choose the side of the meter to attach the arm.
- 3. Use a clean surface and turn the meter over.
- 4. Release the existing screw from the back of the meter.
- 5. Align the electrode arm base with the circles at the bottom of the meter. The metal post on the electrode arm base should be on the same side as the meter display.
- 6. Take the screw that was removed and use it to secure the electrode arm base to the meter.
- 7. Turn the meter over.
- 8. Place the hole at the bottom of the electrode arm onto the metal post on the electrode arm base.

play				
Display Icon	Description PH ready AR			
-	Shown when the meter is running on AC power.			
47776	Shown when the meter has batteries installed.			
ē	Indicates data is being sent to a computer or printer.			
	Indicates data is being sent to the data log.			
-	Shown when an alarm is set and the alarm value is reached.			
85232	Indicates the meter is set to be interfaced with a printer or computer via the RS232 port.			
⊷	Indicates the meter is set to be interfaced with a printer or computer via the USB port.			
07/09/11 09:15	Displays the time and date entered in the setup menu.			
25.0 °C	Displays the current temperature based on the temperature probe reading or entered temperature value. Shows the origin of the temperature as MAN (entered temperature) or ATC (temperature probe).			
HOLD	Shown when $^{\text{treased}}$ is pressed and the displayed measurement is frozen.			
Ľ	Indicates a calibration was successfully completed. Icon will blink when the calibration alarm is set and the alarm value is reached.			
	Indicates the pH electrode condition as good (two bars), fair (one bar) or bad (slash through it), based on the la saved calibration and measurement stability.			
M 100	Indicates a method is in use and the number of the method being used.			
рН	Indicates the type of measurement and determines the type of calibration that will be performed.			
ready	Specifies the stability of the electrode as stabilizing or ready .			
AR	Shown when the meter is in AUTO-READ mode. The AB icon will blink while the reading is stabilizing and stop blinking when the reading is stable and the measurement is locked on the display.			
7.000 pH	Displays the measurement value based on the last saved calibration and current electrode reading. Units are shown to the right of the value.			
0.0mV	Shows the raw millivolt reading of the electrode.			
BUFFERS: 1.68,	Shows the buffer values used for the last saved calibration. pH mode only.			
STANDARDS: 0.10 1.0 10	Shows the standard values used for the last saved calibration. ISE mode only.			
	Shows the operator assigned sample ID number.			
(fr) XXXXXX	Shows the operator assigned user ID number.			
cal	Displays the action that will be performed when f1 is pressed.			
sample ID	Displays the action that will be performed when 12 is pressed.			
channel	Displays the action that will be performed when 13 is pressed.			

Meter Keypad



f1 f2 f3	Press the f1, f2 and f3 function keys to perform the action shown above each key on the display.
	Press to turn the meter on.
	When the meter is on, press and quickly release to turn the display backlight on or off or hold down to turn the meter off.
	In the measurement mode, press to take a measurement.
measure (esc)	In the setup, calibration and other menus, press to escape the current menu and return to the measurement mode.
setup	In the measurement mode, press to enter the setup menu.
	In the setup, calibration and other menus, press to scroll up through a list of options.
hold	In the continuous measurement mode, press to hold (freeze) the displayed measurement and press again to release (unfreeze) the measurement.
	In the setup, calibration and other menus, press to scroll left through a list of options.
mode	In the measurement mode, press to change the displayed measurement mode. Options for channel 1 are pH, mV, RmV (relative mV), ORP and ISE.
	In the setup, calibration and other menus, press to scroll right through a list of options.
	In the measurement mode, press to log or print a measurement.
log/print	In the setup, calibration and other menus, press to scroll down through a list of options.
log view	Press to view the data log and calibration log. Orion Star A214 benchtop meters only.
stirrer	Press to start or stop the stirrer probe. Orion Star A214 benchtop meters only.

- 1. Press (*) to power the meter on. When the meter is on, press and quickly release (*) to turn the backlight on or off or press and hold (*) for about three seconds to power the meter off.
- 2. Press to exit any meter function and return to the measurement mode.
- 3. The *f1, f2*, and *f3* function keys perform a variety of meter operations. The menu-specific operation is shown above each key on the display. For example, press *f1* in the measurement mode to start a calibration.
- 5. In the continuous measurement mode, when key will be functional until the measurement is released (unfrozen).
- 6. Press (stirrer) to turn on or off the stirrer probe (Cat. No. 096019). Orion Star A214 benchtop meters only.
- 7. Press (109 view) to access the calibration log and data log. *Orion Star A214 benchtop meters only.*

Meter Maintenance

For routine meter maintenance, dust and wipe the meter with a damp cloth. If necessary, warm water or a mild water-based detergent can be used. Meter maintenance can be performed on a daily, weekly or monthly basis, as required by the environment in which the meter is operated. Immediately remove any spilled substance from the meter using the proper cleaning procedure for the type of spill.

Chapter 3 Meter Setup

Navigating the Setup Menu

- 1. In the measurement mode, press (to enter the main setup menu.
- 3. Press or to scroll through setup submenu options. Press **f3 (select)** to select a setup submenu option.
- 4. Perform the appropriate actions to set the desired parameter in the setup submenus.
 - a. To select a value from a list of options, press or to highlight the desired value and press **f3 (select)** to set the value.
 - b. To enter a numeric value, use the numeric entry screen.
 - i. Select the value to be entered by pressing f3 (select) or f3 (edit). The numeric entry screen will popup on the display.

 - iii. Press **f2 (done)** to save the value and exit the numeric entry screen.

5. Press **f1 (back)** and then **(back)** to return to the measurement mode at any time.

Setup Menu Overview

pH/ISE Channel	Settings	Log View	Diagnostics
Method Mode & Settings • Measure Mode • Read Type • Resolution • Buffer Group (pH only) • Measure Unit (ISE only) • Blank Correct (ISE only) • Low Level Stability (ISE only) • Stability • Averaging • Limit Alarm • Cal Due Alarm	 Export Data Data Log Date / Time Language Key Press Beep Alarm Beep Stirrer (<i>Star A214 meters only</i>) Contrast Auto Shut Off User ID Sample ID 	 Data Log Calibration Log 	 Factory Reset User Reset Self Test Stability Test About Meter
Temperature			
 Manual Temp Value Temperature Unit Temperature Calibration 			

pH/ISE Channel Menu

The pH/ISE Channel setup menu is used to review and change parameters relating to pH, mV, relative mV, ORP and ISE measurements and calibrations.

Main Setup Menu	2nd Level	3rd Level	Menu Options	Menu Description
pH/ISE Channel	Method	List of Methods		Menu allows the current meter settings to be saved as a new method, an existing method to be run on the meter, or an existing method to be viewed, edited, copied, deleted or printed.
	Mode and Settings	Measure Mode	 pH mV RmV ORP ISE 	Menu used to select the displayed measurement mode, which determines the type of calibration the meter will perform.
		Read Type	• Auto • Continuous • Timed	Menu used to select how the meter will take measurements. Auto (AB) – Press to take a measurement. When the measurement is stable, it is locked on the display until is pressed again. Continuous – The measurement is constantly updated on the display and <i>stabilizing</i> or <i>ready</i> is shown to indicate the measurement stability.
				Timed – Measurements are taken at a set time interval. To enter the time interval, highlight • Timed press • to highlight the hours (HH), minutes (MM) or seconds (SS), press f3 (edit) and use the numeric entry screen to change the values.
		Resolution (pH mode)	 1 Decimal Place 0.1 2 Decimal Places 0.01 3 Decimal Places 0.001 	Menu used to select the resolution for the displayed measurement values.
		Resolution (ISE mode)	 1 significant digit 2 significant digits 3 significant digits	Menu used to select the resolution for the displayed measurement values.
		Buffer Group (pH mode)	• USA • DIN	Menu used to select the buffer group used for automatic buffer recognition during pH calibrations. USA – pH 1.68, 4.01, 7.00, 10.01, 12.46 buffers DIN – pH 1.68, 4.01, 6.86, 9.18 buffers
		Measure Unit (ISE mode)	 ppm M mg/L Percentage (%) ppb None 	Menu used to select the units displayed with ISE measurements.
		Blank Correct (ISE mode)	• Yes • No	Menu used to turn automatic blank (non-linear) correction on or off for ISE measurements. The automatic blank correction feature uses an algorithm to compensate for the non-linearity of an ion selective electrode in low level standards and samples.
		Low Level Stability (ISE mode)	• Off • On	Menu used to turn low level stability on or off for ISE measurements. The low level stability feature improves the accuracy of low concentration ISE measurements by allowing the electrode to have a longer amount of time to stabilize in calibration standards (about three to five minutes)

pH/ISE Channel Menu (cont.)

Main Setup Menu	2nd Level	3rd Level	Menu Options	Menu Description
		Stability	 Smart Stability Fast Medium Slow 	Menu used to select how the stability of the displayed measurement values is indicated. Smart Stability automatically compensates for measurement conditions and optimizes the meter response time.
		Averaging	Off Automatic Smart	Menu used to turn the averaging function on or off. Automatic Smart automatically compensates for measurement conditions and optimizes the meter response time.
pH/ISE Channel (cont.)	Mode and Settings (cont.)	Limit Alarm	 Limit Alarm On Off Alarm Settings Low High High/Low High Limit Low Limit 	Menu used to turn the limit alarm on or off and to set the limit alarm parameters. The limit alarm is triggered if the measurement goes above a high value and/or below a low value set by the operator. Press or to change the setting on each line, press for to select another line and use the numeric entry screen to enter limit values.
		Cal Due Alarm	 Cal Due Alarm On Off Cal Due Limit 	Menu used to turn the calibration due alarm on or off and to set the calibration due alarm time. The calibration due alarm is triggered if a set amount of time has passed without a calibration being performed. Press (ref) or (ref) to change the setting on the top line, press (ref) or (ref) to select another line and use the numeric entry screen to enter the calibration due value in hours.
	Temperature	Manual Temp Value	Default value or last entered value	Menu used to set the temperature value that will be used for all measurements and calibrations. Use the numeric entry screen to enter the temperature.
		Temperature Unit	CelsiusFahrenheit	Menu used to select the temperature units.
		Temperature Calibration	• ATC	Menu allows the temperature measured by an ATC probe (separate or built in to an electrode) to be adjusted by the operator.
		Temperature Input	ATCManual	Menu used to select the source of the temperature measurement.

Settings Menu

The Settings setup menu is used to review and change parameters relating to the general operation of the meter.

Main Setup Menu	2nd Level	Menu Options	Menu Description
Settings	Export Data	 Printing On Off Comm Setup RS232 USB Data Format Printer PC (CSV) Comm Config 1200 2400 4800 9600 19200 38400 	Menu used to turn data exporting on or off, set the meter to be interfaced using the RS232 or USB port, set the exported data format for a printer (string of text) or PC (comma delimited text) and set the baud rate.
	Data Log	OffOn	Menu used to turn on or off the data log feature.
	Date / Time	 Date DD/MM/YY MM/DD/YY Time 12 Hour Clock 24 Hour Clock 	Menu used to set the date format as day/month/year or month/day/year; enter the date values; set the time format as 12 hour or 24 hour clock; and enter the time values. Use the numeric entry screen to enter the values.
	Language	 English Spanish German French Italian Chinese 	Menu used to set the language for all displayed meter prompts.
	Key Press Beep	• Off • On	Menu used to turn on or off the beep sound made every time a meter key is pressed.
	Alarm Beep	OffOn	Menu used to turn on or off the beep sound made when an alarm value is reached.

Settings Menu (cont.)

Main Setup Menu	2nd Level	Menu Options	Menu Description
Settings (cont.)	Stirrer	 Speed 1 Speed 2 Speed 3 Speed 4 Speed 5 	Menu used to turn the stirrer probe on or off and to set the stirrer probe speed. Star A214 meters only.
	Contrast	 Level 1 Level 2 Level 3 Level 4 Level 5 Level 6 	Menu used to set the display contrast.
	Auto Shut Off	OffOn	Menu used to turn on or off the meter automatic shutoff feature, which turns the meter off when no keys are pressed for 20 minutes.
	User ID	Default value or last entered value	Menu used to set the user ID. Use the alphanumeric entry screen to enter the user ID.
	Sample ID	 Off Manual Auto Incremental	Menu used to turn the sample ID off or on. When sample ID is set to manual or auto incremental, enter the sample ID in the measurement mode by pressing <i>f2 (sample ID)</i> and using the alphanumeric entry screen.

View Log Menu

The View Log setup menu is used to access information stored in the data log and calibration log. Refer to the Data Storage and Retrieval chapter for detailed information on using this setup menu.

Diagnostics Menu

The Diagnostics setup menu is used to perform the meter self-test, reset the meter to the factory default settings and display meter information including serial number and software revision. Refer to the Customer Services chapter for detailed information on using this setup menu.

This page intentionally left blank.

Chapter 4 pH, RmV and ORP Calibration

The Orion Star A200 and Star A300 series pH meters can perform a one to five point pH calibration, one point relative mV calibration and one point ORP calibration. Step-by-step instructions and prompts are displayed on the meter to assist operators with the calibration menus. The meter can save up to 10 calibrations in the log and calibration data can be exported from the meter to a printer or computer.

pH Calibration

One to five pH buffers can be used for calibration. Always use fresh pH buffers and select buffers that bracket the sample pH and are one to four pH units apart. Prepare the pH electrode according to the instructions in the electrode use guide. Connect the pH electrode and any other electrodes to be used (stirrer probe, ATC probe, reference electrode) to the meter. Power on the meter and set the measurement mode to pH.

Note: In most calibration screens, press f1 (esc) to return to the measurement mode without saving the calibration.

- 1. In the measurement mode, press f1 (cal).
- 2. Rinse the pH electrode and any other electrodes in use with distilled water, blot dry with a lint-free tissue and place into the pH buffer.
- When the electrode and buffer are ready, press f3 (start). If using a Star A214 benchtop meter and stirrer probe, the stirrer probe will automatically start stirring at the speed selected in the setup menu once f3 (start) is pressed and stop stirring once the reading stabilizes.
- 4. Wait for the pH value on the meter to stabilize and stop flashing and perform one of the following actions:
 - a. Press f2 (accept) to accept the displayed value.
 - b. Press f3 (edit) to access the numeric entry screen and edit the value.
 - i. Press (***), (***), (***) or (***) to highlight a number, decimal point or negative sign; press **f3 (enter)** to select the highlighted item and repeat until the value at the measured temperature is shown above the numeric entry screen.
 - ii. Press *f2 (done)* to exit the numeric entry screen.
 - iii. Press *f2 (accept)* to accept the entered value.
- Press *f2 (next)* to proceed to the next buffer and repeat steps 2 through 4 or press *f3 (cal done)* to save and end the calibration. If five buffers are used, the calibration will save and end once the fifth value is accepted.
 - a. If a one point calibration is performed, press *f2 (accept)* to accept the displayed slope value or press *f3 (edit)* to access the numeric entry screen, enter the slope value and press *f2 (accept)*.
- The meter will display the calibration summary including the average slope and export the data to the calibration log. Press *f1 (meas)* to proceed to the measurement mode or press *f2 (print)* to proceed to the measurement mode and export the data to a printer or computer.

Calibration Editing

- 1. In the calibration summary display (pH calibration step 6), press f3 (cal edit) to edit the calibration points.
- 2. Press or to highlight the calibration point to be edited and press **f2** (select).
- 3. Press or to highlight *Remeasure, Edit* or *Delete* and press *f2 (select)*.
 - a. If *Remeasure* is selected, repeat pH calibration steps 2 through 4.
 - b. If *Edit* is selected, press *f3 (edit)* to access the numeric entry screen, enter the new value, press *f2 (done)* and then press *f2 (accept)*. Select another calibration point to edit or press *f1 (back)*.
 - c. If *Delete* is selected, the calibration point will be deleted. If deleting the calibration point changes the calibration to a one point calibration, enter the slope using the numeric entry screen.
- 4. The meter will display an updated calibration summary and export the data to the calibration log. Press f1 (meas) to proceed to the measurement mode, press f2 (print) to proceed to the measurement mode and export the data to a printer or computer or press f3 (cal edit) to edit another calibration point.

RmV Calibration

One standard can be used for a relative mV calibration. Always use fresh standard. Prepare the electrode according to the instructions in the electrode use guide. Connect the electrode and any other electrodes to be used (stirrer probe, ATC probe, reference electrode) to the meter. Power on the meter and set the measurement mode to RmV.

Note: In most calibration screens, press **f1 (esc)** to return to the measurement mode without saving the calibration.

- 1. In the measurement mode, press **f1 (cal)**.
- 2. Rinse the electrode and any other electrodes in use with distilled water, blot dry with a lint-free tissue and place into the standard.
- When the electrode and standard are ready, press *f3 (start)*. If using a Star A214 benchtop meter and stirrer probe, the stirrer probe will automatically start stirring at the speed selected in the setup menu once *f3 (start)* is pressed and stop stirring once the reading stabilizes.
- 4. Wait for the mV value on the meter to stabilize, indicated by the flashing **stabilizing** or solid **ready** icon, and perform one of the following actions:
 - a. Press f2 (accept) to accept the mV value shown on the Rel Value line.
 - b. Press f3 (edit) to access the numeric entry screen and edit the mV value shown on the Rel Value line.

 - ii. Press *f2 (done)* to exit the numeric entry screen.

iii. Press f2 (accept) to accept the entered mV value.

5. The meter will display the calibration summary including the mV offset and export the data to the calibration log. Press *f1 (meas)* to proceed to the measurement mode or press *f2 (print)* to proceed to the measurement mode and export the data to a printer or computer.

ORP Calibration

The mV reading of an ORP standard is dependent on the ORP electrode reference system, reference material and filling solution as well as the ORP standard temperature. An ORP electrode can be automatically calibrated to read 420 mV relative to the Standard Hydrogen Electrode ($E_{\rm H}$) at 25°C when the Orion ORP standard (Cat. No. 967901 or 967961), Orion ORP electrode (Cat. No. 9678BNWP, 9778BNWP, 9180BNMD or 9179BNMD) and Orion 4 M KCl filling solution (Cat. No. 900011) or 4 M KCl gel (in Cat. No. 9179BNMD) are used. The raw mV reading of an electrode with the same conditions is 220 mV at 25 °C.

The Thermo Scientific Orion ORP standard is nonhazardous, stable and will not change over time, so it is an ideal standard for any ORP measurement system. The Orion Star A200 and Star A300 series pH meters offer a simple, automatic calibration to the $E_{\rm H}$ value in the ORP mode when using Orion ORP electrodes and standard. Visit www.thermoscientific.com/water for ORP application notes that include a table of ORP standard values at different temperatures.

One standard can be used for ORP calibration. Always use fresh ORP standard. Prepare the ORP electrode according to the instructions in the electrode use guide. Connect the electrode and any other electrodes to be used (stirrer probe, ATC probe, reference electrode) to the meter. Power on the meter and set the measurement mode to ORP.

Note: In most calibration screens, press f1 (esc) to return to the measurement mode without saving the calibration.

- 1. In the measurement mode, press f1 (cal).
- 2. Rinse the ORP electrode and any other electrodes in use with distilled water, blot dry with a lint-free tissue and place into the standard.
- When the electrode and standard are ready, press *f3 (start)*. If using a Star A214 benchtop meter and stirrer probe, the stirrer probe will automatically start stirring at the speed selected in the setup menu once *f3 (start)* is pressed and stop stirring once the reading stabilizes.
- Wait for the mV value on the meter to stabilize, indicated by the flashing stabilizing or solid ready icon, and press f2 (accept) once the value is stable.
- The meter will display the calibration summary including the mV offset and export the data to the calibration log. Press *f1 (meas)* to proceed to the measurement mode or press *f2 (print)* to proceed to the measurement mode and export the data to a printer or computer.

This page intentionally left blank.

Chapter 5 ISE Calibration

ISE Calibration

One to five standards can be used for ISE calibration. If more than one standard is used to calibration, start with the lowest concentration standard and work up to the highest concentration standard last. Always use fresh standards. Select standards that bracket the sample concentration and are a decade apart in concentration. Prepare the ion selective electrode according to the instructions in the electrode use guide. Connect the ISE and any other electrodes to be used (stirrer probe, ATC probe, reference electrode) to the meter. Power on the meter and set the measurement mode to ISE.

Note: In most calibration screens, press f1 (esc) to return to the measurement mode without saving the calibration.

- 1. In the measurement mode, press f1 (cal).
- 2. Rinse the ion selective electrode and any other electrodes in use with distilled water, blot dry with a lint-free tissue and place into the ISE standard.
- When the electrode and standard are ready, press *f3 (start)*. If using a Star A214 benchtop meter and stirrer probe, the stirrer probe will automatically start stirring at the speed selected in the setup menu once *f3 (start)* is pressed and stop stirring once the reading stabilizes.
- 4. Wait for the concentration value on the meter to stabilize and stop flashing and perform one of the following actions:
 - a. Press *f2 (accept)* to accept the displayed value.
 - b. Press f3 (edit) to access the numeric entry screen and edit the value.
 - i. Press (, ,), (
 - ii. Press f2 (done) to exit the numeric entry screen.
 - iii. Press *f2 (accept)* to accept the entered value.
- Press *f2 (next)* to proceed to the next standard and repeat steps 2 through 4 or press *f3 (cal done)* to save and end the calibration. If five standards are used, the calibration will save and end once the fifth value is accepted.
 - a. If a one point calibration is performed, press *f2 (accept)* to accept the displayed slope value or press *f3 (edit)* to access the numeric entry screen, enter the slope value and press *f2 (accept)*.
- 6. The meter will display the calibration summary including the average slope and export the data to the calibration log. Press *f1 (meas)* to proceed to the measurement mode or press *f2 (print)* to proceed to the measurement mode and export the data to a printer or computer.

Calibration Editing

- 1. In the calibration summary display (ISE calibration step 6), press f3 (cal edit) to edit the calibration points.
- 2. Press or with to highlight the calibration point to be edited and press **f2** (select).
- 3. Press or bighlight *Remeasure*, *Edit* or *Delete* and press *f2 (select)*.
 - a. If *Remeasure* is selected, repeat ISE calibration steps 2 through 4.
 - b. If *Edit* is selected, press *f3 (edit)* to access the numeric entry screen, enter the new value, press *f2 (done)* and then press *f2 (accept)*. Select another calibration point to edit or press *f1 (back)*.
 - c. If *Delete* is selected, the calibration point will be deleted. If deleting the calibration point changes the calibration to a one point calibration, enter the slope using the numeric entry screen.
- 4. The meter will display an updated calibration summary and export the data to the calibration log. Press f1 (meas) to proceed to the measurement mode, press f2 (print) to proceed to the measurement mode and export the data to a printer or computer or press f3 (cal edit) to edit another calibration point.

Chapter 6 Temperature Calibration

The meter ATC temperature display has a relative accuracy of ± 0.1 °C. ATC probes (both separate and those built into electrodes) have varying temperature accuracies, usually ± 0.5 °C to ± 2 °C. Use this function only if it is necessary to calibrate the temperature readings taken by the ATC probe. Since the temperature offset calculated during the calibration is applied to all future temperature measurements, recalibrate if a different ATC probe is used.

Temperature calibration is for the calibration of an ATC probe (separate or built in to a pH electrode or ORP electrode). If manual temperature compensation is being used and the display shows MAN as the temperature source icon, set the manual temperature value using the Manual Temp Value menu. The temperature calibration menu is not accessible unless an ATC probe is connected to the meter.

- 1. In the measurement mode, press (\bullet) .
- 2. Press (****), (****), (****) or (****) to highlight *pH/ISE Channel* and press *f3 (select)*.
- 3. Press or with to highlight *Temperature* and press *f3 (select)*.
- 4. Press or very to highlight *Temperature Calibration* and press **f3 (select)**.
- 5. Press () or () to highlight *ATC* to identify the ATC probe that will be calibrated and press *f3 (select).*
- Place the ATC probe and thermometers into a solution with a known, stable temperature. It is recommended that two NIST traceable thermometers be used to measure and verify the temperature of the solution.
- 7. Wait for the temperature readings of the ATC probe and thermometers to stabilize (usually two to five minutes).
- 8. Press f3 (edit) to access the numeric entry screen and edit the temperature value.
 - a. Press (more, (more), (more), (more) or (more) to highlight a number, decimal point or negative sign; press **f3 (enter)** to select the highlighted item and repeat until the temperature value read by the thermometers is shown on the display.
 - b. Press f2 (done) to exit the numeric entry screen.
- 9. The meter will display the entered temperature value on the *Reference Temp* line, the original temperature read by the ATC probe on the *ATC* line and the temperature offset value that will be applied to all future temperature readings on the *Offset* line. Press *f2 (accept)* to proceed with the displayed temperature data, save and end the calibration and export the data to the calibration log.
- 10. Press **f1 (meas)** to proceed to the measurement mode or press **f2 (print)** to proceed to the measurement mode and export the data to a printer or computer.

This page intentionally left blank.

Chapter 7 Measurement

The Orion Star A214 and Star A324 meters are capable of showing pH, mV, RmV (relative mV), ORP or ISE measurements on the display.

Press while taking a measurement in the continuous measurement mode to freeze the display and press a second time to unfreeze the display and continue the measurement. Press while taking a measurement to manually export the measurement to the data log, if the data log is enabled in the setup menu.

- 1. Rinse the pH electrode or ion selective electrode (ISE) and any other electrodes in use with distilled water, blot dry with a lint-free tissue and place into the sample.
- Star A214 meters only If the stirrer probe is in use and the meter is in continuous or timed mode, press (stirrer) to turn on the stirrer probe. If the stirrer probe is in use and the meter is in AUTO-READ mode, the stirrer probe will start stirring when (stirrer) is pressed and stop stirring when the reading stabilizes.
- 3. Start the measurement and wait for it to stabilize.
 - a. If the meter is in AUTO-READ mode (default setting), press to start the measurement. When the AR icon stops flashing, record the applicable measurement parameters and temperature of the sample. Press again to start a new measurement.
 - b. If the meter is in continuous mode, the meter will immediately start taking a measurement and update the display whenever the measurement changes. Wait for the display to show **ready** and record the applicable measurement parameters and temperature of the sample.
 - c. If the meter is in timed mode, the meter will log measurements at the preselected time interval, regardless of the measurement stability. The meter will update the display whenever the measurement changes, so the applicable measurement parameters and temperature of the sample can be recorded when the display shows **ready**.
- 4. *Star A214 meters only* If the stirrer probe is in use and the meter is in continuous or timed mode, press to turn off the stirrer probe.
- 5. Remove the electrodes from the sample, rinse with distilled water, blot dry and place into the next sample.
- 6. Repeat steps 2 through 5 for all samples.
- 7. When all samples have been measured, store the electrodes according to their user guides.

This page intentionally left blank.

Chapter 8 Methods

The Orion Star A214 and Star A324 meters can save up to ten methods per channel and the corresponding calibration data for each method, for the fast and easy recollection of different meter setup parameters. The default meter setting is that no method is used and the method number will be shown as M100 if no method is in use. The current meter settings can be saved in the setup menu. Existing methods can be selected from the methods list and run on the meter. Methods can be viewed, edited, copied to a new method or deleted.

Saving the Current Meter Settings as a New Method

- 1. In the measurement mode, press $\begin{pmatrix} setup \\ \blacktriangle \end{pmatrix}$.
- 2. Press (****), (****), (****) or (****) to highlight *pH/ISE Channel* and press *f3 (select)*.
- 3. Press or view to highlight *Method* and press **f3** (select).
- 4. The meter will display *Current Settings* and a list of methods. The list will show the sequential number of the methods (*M101*) and the date, time and mode of each method (*07/01/11 12:45 pH*) if methods have been previously created.
- 5. Press or to highlight *Current Settings* and press *f3 (save)*.
- 6. Press or bighlight a method number that the current settings will be saved as and press **f2** (accept).
- 7. The meter will prompt for a method specific password to be created. The password must be at least 3 characters long.
 - a. Press f3 (edit) to access the numeric entry screen.

 - c. Press f2 (done) to exit the numeric entry screen.
 - d. Press f2 (accept) to accept the entered password.
- 8. The meter will automatically proceed to the measurement mode.

Loading an Existing Method

- 1. In the measurement mode, press (
- 3. Press or view to highlight *Method* and press *f3 (select)*.
- 4. The meter will display *Current Settings* and a list of methods. The list will show the sequential number of the methods *(M101)* and the date, time and mode of each method *(07/01/11 12:45 pH)* if methods have been previously created.
- 5. Press or very to highlight the method to be loaded and press **f2 (load)**.
- 6. The meter will automatically proceed to the measurement mode.

Editing, Copying or Deleting an Existing Method

- 1. In the measurement mode, press
- 3. Press or buildinght *Method* and press **f3 (select)**.
- The meter will display *Current Settings* and a list of methods. The list will show the sequential number of the methods (*M101*) and the date, time and mode of each method (*07/01/11 12:45 pH*) if methods have been previously created.
- 5. Press or brighlight the desired method and press **f3 (options)**.
- 6. Enter the method specific password.
 - a. Press f3 (edit) to access the numeric entry screen.
 - b. Press (****), (****), (****) or (****) to highlight a number, press **f3 (enter)** to select the highlighted number and repeat until the password is shown.
 - c. Press f2 (done) to exit the numeric entry screen.
 - d. Press *f2 (accept)* to accept the entered password.
- 7. Press or very to highlight *Edit, Copy* or *Delete* and press *f2 (accept)*.
 - a. If *Edit* is selected press or *select* or *select*. To highlight any setup menu parameters that need to be changed and press *f3 (select*). Review and change all applicable setup menu parameters. Press *f1 (back)* to return to the list of methods and then press *f3* to return to the measurement mode.
 - b. If *Copy* is selected press or vert to highlight a method number that the selected method will be copied to and press *f2 (accept)*. The meter will automatically proceed to the measurement mode.
 - c. If *Delete* is selected press *f2 (yes)* to delete the method or press *f3 (no)* to keep the method. The meter will automatically proceed to the measurement mode.

Chapter 9 Data Storage and Retrieval

Data Storage Settings

The data and calibration storage settings include the measurement read type, computer and printer export settings and data log settings. The measurement read type determines when the meter sends measurements to the data log, if the data log is enabled in the setup menu, and to a printer or computer, if a printer or computer is connected to the meter and enabled in the setup menu. Review the date and time settings and update as needed.

Read Type Selection

- 1. In the measurement mode, press (****).
- 3. Press or with to highlight *Mode and Settings* and press *f3 (select)*.
- 4. Press or view to highlight *Read Type* and press *f3 (select)*.
- 5. Press or with to highlight *Auto, Continuous* or *Timed* and press *f3 (select)*.
 - a. If *Timed* is selected and the time interval needs to be changed highlight *Timed*; press to highlight hours (HH), minutes (MM) or seconds (SS); press *f3 (edit)* to access the numeric entry screen; use the numeric entry screen to change the values and press *f1 (back)* when the time interval is correct.
- 6. Press to return to the measurement mode.

Computer and Printer Export Settings

- 1. In the measurement mode, press (
- 2. Press (*****), (****), (****) or (**** to highlight *Settings* and press *f3 (select)*.
- 3. Press or to highlight *Export Data* and press *f3 (select)*.
- 4. Press or very to highlight *Printing* and press *f3 (select)*. Press or very to highlight *On* or *Off* and press *f3 (select)*. Select *On* to allow data to be sent to a computer or printer.
- 5. Press or we to highlight *Comm Setup* and press *f3 (select)*. Press or we to highlight *RS232* or *USB* and press *f3 (select)*. Select *RS232* if the meter will be interfaced using the RS232 port and select *USB* if the meter will be interfaced using the USB port.
- 6. Press or which to highlight *Data Format* and press *f3 (select)*. Press or which to highlight *Printer* or *PC (CSV)* and press *f3 (select)*. Select *Printer* to export the data as a string of text and select *PC (CSV)* to export the data in comma delimited format.
- Press or very to highlight *Comm Config* and press *f3 (select)*. Press or very to highlight *1200, 2400, 4800, 9600, 19200* or *38400* and press *f3 (select)*. Select the baud rate best for the data transfer requirements. The fixed meter output settings are 8 bits, 1 stop bit and parity none.
- 8. Press **f1 (back)** and then press **f** to return to the measurement mode.

Data Log Settings

- 1. In the measurement mode, press $\begin{pmatrix} setup \\ \blacktriangle \end{pmatrix}$.
- 3. Press or very to highlight *Data Log* and press *f3 (select)*.
- 4. Press or very to highlight *Off* or *On* and press *f3 (select)*.
- 5. Press **f1 (back)** and then press **f1 (back)** to return to the measurement mode.

Viewing the Calibration Log and Data Log

The Orion Star A200 and Star A300 series meters save up to ten of the most recent calibrations per channel. The Star A214 meter saves up to 2000 sets of data points and the Star A324 meter saves up to 5000 sets of data points. A log number is assigned to each data point. The read type of the displayed channel or channels determines when measurements are exported to the data log. When a data point is exported to a computer or printer, the time stamp will include the hour, minutes and seconds.

Viewing the Calibration Log

- 1. In the measurement mode, press (
- 3. Press or before to highlight *Calibration Log* and press *f2 (accept)*.
- 4. Press or bighlight *pH/ISE Channel* and press *f2 (select)*.
- 5. Press or broken to highlight *pH, RmV, ORP* or *ISE* and press *f2 (select)*.
- 6. The meter will display a list of calibrations for the selected channel and calibration type. The list shows the sequential number of the calibration and the date and time it was saved (07/01/2011 12:45).
- To view the calibration data, press or view to highlight a specific calibration and press *f2 (select)*. Press *f2 (print)* to print the calibration, press *f3 (info)* to view the electrode slope between pH buffer or ISE standard points or press *f1 (back)* to return to the list of calibrations.
- 8. Press to return to the measurement mode.

Viewing the Data Log

- 1. In the measurement mode, press (\bullet) .
- 2. Press (*****), (*****), (*****) or (***** to highlight *View Log* and press *f3 (select)*.
- 3. Press $(\overset{\text{stop}}{\frown})$ or $(\overset{\text{vertex}}{\frown})$ to highlight *Data Log* and press *f2 (accept)*.
- 4. Press () or () ot highlight *pH/ISE Channel* and press *f2* (*select*).
- 5. The meter will display a list of the data points. The list shows the sequential number of the data point and the date and time the data point was saved (07/01/2011 12:45).
- 6. To view the measurement information for an individual data point, press or view to highlight the data point and press *f2 (select)*. Press *f2 (print)* to print the data point or press *f1 (back)* to return to the list of data points.
- 7. Press to return to the measurement mode.

Exporting the Data Log to a Computer or Printer

- 1. In the measurement mode, press $\begin{pmatrix} setup \\ \blacktriangle \end{pmatrix}$
- 2. Press $(\overset{\text{step}}{\frown})$, $\overset{\text{mode}}{\frown}$, $\overset{\text{mode}}{\frown}$ or $\overset{\text{mode}}{\frown}$ to highlight *View Log* and press *f3 (select)*.
- 3. Press or very to highlight *Data Log* and press *f2 (accept)*.
- 4. Press or to highlight *pH/ISE Channel* and press *f3 (select)*.
- 5. The meter will display a list of the data points. The list shows the sequential number of the data point and the date and time the data point was saved (07/01/2011 12:45).
- 6. Press f3 (options).
- 7. Press or very to highlight *Log Export* and press *f2 (accept)*.
- 8. Press or vertex to highlight *Today, Last 10, Range* or *All* as the data log points to be exported and press *f2 (accept)*.
 - a. If Today, Last 10 or All is selected press f2 (yes) to export the data.
 - b. If *Range* is selected enter the first and last date points:
 - i. Press f3 (edit) to display the numeric entry screen.
 - ii. Press (****), (****), (****) or (****) to highlight a number, press **f3 (enter)** to select the highlighted number and repeat until the number of the first data point to be exported is shown on the display.
 - iii. Press f2 (done) to exit the numeric entry screen.
 - iv. Press (\mathbf{v}) to enter the last data point.
 - v. Press f3 (edit) to display the numeric entry screen.
 - vi. Press (****), (****), (*****) or (*****) to highlight a number, press **f3 (enter)** to select the highlighted number and repeat until the number of the last data point to be exported is shown on the display.
 - vii. Press f2 (done) to exit the numeric entry screen.
 - viii. Press f2 (accept) and then press f2 (yes) to export the data.
- 9. After exporting the data, the meter will automatically return to the measurement mode.

Clearing the Data Log

- 1. In the measurement mode, press
- 2. Press (\mathbf{A}) , (\mathbf{A}) , (\mathbf{A}) , (\mathbf{A}) , (\mathbf{A}) or (\mathbf{A}) to highlight *View Log* and press **f3** (select).
- 3. Press or buy to highlight *Data Log* and press *f2 (accept)*.
- 4. Press or view to highlight *pH/ISE Channel* and press *f3 (select)*.
- 5. The meter will display a list of the data points. The list shows the sequential number of the data point and the date and time the data point was saved (07/01/2011 12:45).
- 6. Press f3 (options).
- 7. Press or to highlight *Log Clear* and press *f2 (accept)*.
- 8. Press *f2 (yes)* twice to clear the entire data log.
- 9. Enter the password. The default is 111111 and pressing f2 (accept) will advance the meter to the next step.
- 10. Press **f1 (back)** and then press **6** to return to the measurement mode.

Interfacing a Printer

The Orion Star printer, Cat. No. 1010006, is recommended for use with the Orion Star A200 and Star A300 series meters. The Orion Star printer has a 9600 baud rate and it is packaged with the RS232 printer cable, Cat. No. 250302-001, which is required to interface an Orion Star A meter to a printer. The baud rate of the Orion Star A200 and Star A300 series meters can be set to 1200, 2400, 4800, 9600, 19200 or 38400 for communication to different printers. The fixed meter settings are: number of bits = 8, stop bits = 1, parity = none. The flow control for the printer should be set to XON/XOFF. The meter will send measurements and calibration data to the printer if the printer option is turned on in the setup menu. Alternatively, measurements and calibration data can be sent to the data log and calibration log. From the data log and calibration log, the operator can chose to print a single data log point, a range of data log points or the entire data log.

Interfacing a Computer

The Orion Star A200 and Star A300 series meters can send measurements and calibration data to a computer in a comma delimited format that is easy to parse in computer programs like Excel. Connect the RS232 computer cable, Cat. No. 1010053, to the RS232 input on the meter and the RS232 input on a computer. The baud rate of the Orion Star A series meters can be set to 1200, 2400, 4800, 9600, 19200 or 38400. The fixed meter settings are: number of bits = 8, stop bits = 1, parity = none. The flow control for the computer should be set to XON/XOFF. The meter will send measurements and calibration data to the computer if the computer option is turned on in the setup menu. Alternatively, measurements and calibration data can be sent to the data log and calibration log. From the data log and calibration log, the operator can chose to send a single data log point, a range of data log points or the entire data log to the computer.

A complimentary copy of general data logging software is available for use with the Orion Star A200 and Star A300 series meters. This can be found on the CD included with the meter or at www.thermoscientific.com/water.

Chapter 10 Customer Services

Meter Errors and Recommended Actions

Error	Recommended Actions		
Display Error	If this error occurs, contact Technical Support.		
Hardware Error	If this error occurs, contact Technical Support.		
Channel Input Error	Disconnect all of the electrodes from the meter, connect the BNC shorting cap to the BNC inputs and repeat the self test.		
Reference Input Error	Make sure that all of the electrodes are disconnected from the meter (including the reference input), connect the BNC shorting cap to the BNC input and repeat the self test.		
Ground Input Error	Make sure that all of the electrodes are disconnected from the meter (including the ground input), connect the BNC shorting cap to the BNC input and repeat the self test.		
Keypad Failure	Repeat the self test. When the meter prompts, press each of the keys one at a time, including the power key, within five seconds of one other. If the error persists, contact Technical Support.		
Over Range Measurement or Under Range Measurement	If the measurement is flashing 9999 and over range or under range, the measurement value is outside of the allowable measurement range. Make sure that the electrode is connected to the appropriate meter input and the electrode parameters are entered correctly in the setup menu. Clean the electrode according to the electrode user guide and re-calibrate the electrode with new buffers or standards. If the error persists, perform the meter self test.		
Measurement Out of Range	Make sure that the electrode is connected to the appropriate meter input and the electrode parameters are entered correctly in the setup menu. Clean the electrode according to the electrode user guide and re-calibrate the electrode with new buffers or standards. Perform the meter self test.		

Meter Self Test and Checkout

Meter Self Test

- 1. In the measurement mode, press setup (
- 2. Press (****), (****), (****) or (****) to highlight *Diagnostics* and press **f3 (select)**.
- Press or very to highlight Self Test and press f2 (accept).
- 4. Disconnect all of the electrodes and probes from the meter, attach the BNC shorting cap to the BNC input and press f2 (yes).
- 5. Press f2 (yes) to start the self test.
- 6. The meter will perform an accuracy test. When the meter displays Accuracy Test Passed, press f2 (next).
- 7. The meter will perform an EPROM test. When the meter displays E2Prom Test Passed, press f2 (next).
- 8. The meter will perform a keypad test. Press each of the keys on the keypad (including) one at a time in any order. When the meter displays *Keypad Test Passed*, press *f2 (next)*.
- 9. The meter will display *Self Test Passed*. Press **()** to return to the measurement mode.

Meter Checkout (pH)

- 1. After the self test is complete, the meter will return to the measurement mode. Keep all of the electrodes disconnected from the meter and keep the BNC shorting cap attached to the BNC input on the meter.
- 2. Set the measurement mode to pH. The meter should read a steady 7.000 pH \pm 0.002 pH. If the meter does not read a steady 7.000 \pm 0.002, perform a one point pH calibration with the BNC shorting cap attached to the BNC input. Set the pH value to 7.000 and the slope value to 100.0. Refer to the pH Calibration section for detailed instructions.
- 3. In the measurement mode, the meter should read a steady 0.0 mV \pm 0.2 mV. If the meter does not read a steady 0.0 mV \pm 0.2 mV with the BNC shorting cap attached to the BNC input, contact Technical Support.

Electrode Stability Test

- 1. In the measurement mode, press (
- 3. Press or very to highlight *Stability Test* and press *f2 (accept)*.
- 4. Press or vertex to highlight *pH/ISE Channel* and press **f2** (*next*).
- 5. Make sure the electrode or probe to be tested is connected to the channel selected in the previous step and press *f2 (yes)*.
- 6. Place the electrode or probe in an appropriate solution with a stable temperature and press f2 (yes).
 - a. Orion pH 7 buffer (Cat. No. 910107, 910760 or 910710) is recommended for testing a pH electrode.
 - b. A calibration standard with a moderate concentration of the ion of interest is recommended for testing an ion selective electrode (ISE).
 - c. Orion ORP standard (Cat. No. 967901 or 967961) is recommended for testing an ORP electrode.
- 7. The meter will perform the stability test and show the mV per minute drift and noise on the display.
- 8. The meter will display *Stability Test Passed* or *Stability Test Failed*. Press **f1 (esc)** or **(Stability Test Failed**. Press **f1 (esc)** or **(Stability Test**

Meter Factory Reset

After a factory reset is performed, all of the meter settings will be reset to the factory defaults and the data log, calibration log and methods will be deleted.

- 1. In the measurement mode, press (
- 2. Press $(\overset{\text{weight}}{\bullet})$, $(\overset{\text{weight}}{\bullet})$, $(\overset{\text{weight}}{\bullet})$ or $(\overset{\text{weight}}{\bullet})$ to highlight *Diagnostics* and press *f3 (select)*.
- 3. Press or vertex to highlight *Factory Reset* and press *f2 (accept)*.
- 4. Press *f2 (yes)* to reset the meter.
- 5. The meter will pause, power off and restart with the factory default settings.

Meter User Reset

After a user reset is performed, all of the meter setup menu settings will be reset to the defaults; however, the data log, calibration log and methods will be retained.

1. In the measurement mode, press (

- 2. Press (\mathbf{A}) , (\mathbf{A}) , (\mathbf{A}) , (\mathbf{A}) , (\mathbf{A}) or (\mathbf{A}) to highlight **Diagnostics** and press **f3** (select).
- 3. Press or to highlight *User Reset* and press *f2 (accept)*.

4. Press *f2 (yes)* to reset the meter.

5. The meter will pause and then return to the measurement mode with the default setup menu settings.

About Meter

- 1. In the measurement mode, press
- 2. Press (*****), (****), (****), (****) or (**** to highlight *Diagnostics* and press *f3 (select)*.
- 3. Press or very to highlight *About Meter* and press *f2 (accept)*.
- 4. The meter model, measurement parameters, serial number and software revision will be displayed.
- 5. Press **f1 (back)** to return to the diagnostics menu or press **f1 (back)** to return to the measurement mode.

Assistance

After troubleshooting all components of your measurement system, contact Technical Support. Within the United States call 1.800.225.1480 and outside the United States call 978.232.6000 or fax 978.232.6031. In Europe, the Middle East and Africa, contact your local authorized dealer. For the most current contact information, visit www. thermoscientific.com/water.

Warranty and Registration

To register your meter and for the most current warranty information, visit www.thermoscientific.com/water.

Ordering Information

	Orion Star A200 Series Benchtop Meters
Cat. No.	Description
STARA2110	Star A211 pH Benchtop Meter with Electrode Stand
STARA2115	Star A211 pH Benchtop Meter with Electrode Stand; 8302BNUMD ROSS pH/ATC Triode; 810199 ROSS pH Buffer Kit
STARA2120	Star A212 Conductivity Benchtop Meter with Electrode Stand
STARA2125	Star A212 Conductivity Benchtop Meter with Electrode Stand; 013005MD Conductivity Cell; 011007 Conductivity 1413µS/cm Standard
STARA2126	Star A212 Conductivity Benchtop Meter with Electrode Stand; 013016MD Conductivity Cell with Detachable Flow Through Cell; 011008 Conductivity 100µS/cm Standard
STARA2130	Star A213 RDO/DO Benchtop Meter with Electrode Stand
STARA2135	Star A213 RDO/DO Benchtop Meter with Electrode Stand; 083005MD Polarographic DO Probe with Calibration Sleeve; 080513 Probe Maintenance Kit; BOD Funnel, Stirrer and Adapter
STARA2136	Star A213 RDO/DO Benchtop Meter with Electrode Stand; 086030MD AUTO-STIR DO/BOD Probe; 080514 Polarographic Electrolyte Solution; 080513 Probe Maintenance Kit
STARA2140	Star A214 pH/ISE Benchtop Meter with Electrode Stand
STARA2145	Star A214 pH/ISE Benchtop Meter with Electrode Stand; 8102BNUWP ROSS Ultra pH Electrode; 927007MD ATC Probe; 096019 Stirrer Probe; 810199 ROSS pH Buffer Kit
STARA2146	Star A214 pH/ISE Benchtop Meter with Electrode Stand; 8102BNUWP ROSS Ultra pH Electrode; 927007MD ATC Probe; 9512HPBNWP High-Performance Ammonia Electrode; 096019 Stirrer Probe; 951007 Ammonia 1000ppm Standard; 951210 Low-level Ammonia ISA; 951213 Ammonia Electrode Storage Solution
STARA2147	Star A214 pH/ISE Benchtop Meter with Electrode Stand; 8102BNUWP ROSS Ultra pH Electrode; 927007MD ATC Probe; 9609BNWP Fluoride Electrode; 096019 Stirrer Probe; 040906 Fluoride 1ppm with TISAB II Standard; 040907 Fluoride 2ppm with TISAB II Standard; 040908 Fluoride 10ppm with TISAB II Standard; 940909 TISAB II
STARA2148	Star A214 pH/ISE Benchtop Meter with Electrode Stand; 8102BNUWP ROSS Ultra pH Electrode; 927007MD ATC Probe; 8611BNWP ROSS Sodium Electrode with Sodium Standards, Reagents and Solutions; 096019 Stirrer Probe
STARA2150	Star A215 pH/Conductivity Benchtop Meter with Electrode Stand
STARA2155	Star A215 pH/Conductivity Benchtop Meter with Electrode Stand; 8157BNUMD ROSS pH/ATC Triode; 013005MD Conductivity Cell; 810199 ROSS pH Buffer Kit; 011007 Conductivity 1413µS/cm Standard
STARA2160	Star A216 pH/RDO/DO Benchtop Meter with Electrode Stand
STARA2165	Star A216 pH/RDO/DO Benchtop Meter with Electrode Stand; 8157BNUMD ROSS pH/ATC Triode; 083005MD Polarographic DO Probe with Calibration Sleeve; 810199 ROSS pH Buffer Kit; 080513 Probe Maintenance Kit; BOD Funnel, Stirrer and Adapter

	Orion Star A200 and Star A300 Series Portable Meters
Cat. No.	Description
STARA2210	Star A221 pH Portable Meter
STARA2215	Star A221 pH Portable Meter; 8107UWMMD ROSS pH/ATC Triode with 3 Meter Cable; 910410 pH 4.01 Buffer Pouches; 910710 pH 7.00 Buffer Pouches; 911010 pH 10.01 Buffer Pouches; 810001 ROSS Electrode Storage Solution; 911110 Rinse Solution Pouches; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA2220	Star A222 Conductivity Portable Meter
STARA2225	Star A222 Conductivity Portable Meter; 013010MD Conductivity Cell with 3 Meter Cable; 01100710 Conductivity 1413µS/cm Standard Pouches; 911110 Rinse Solution Pouches; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA2230	Star A223 RDO/DO Portable Meter
STARA2235	Star A223 RDO/DO Portable Meter; 087010MD RDO Optical DO Probe with 3 Meter Cable; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA3210	Star A321 pH Portable Meter
STARA3215	Star A321 pH Portable Meter; 8107UWMMD ROSS pH/ATC Triode with 3 Meter Cable; 910410 pH 4.01 Buffer Pouches; 910710 pH 7.00 Buffer Pouches; 911010 pH 10.01 Buffer Pouches; 810001 ROSS Electrode Storage Solution; 911110 Rinse Solution Pouches; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA3220	Star A322 Conductivity Portable Meter
STARA3225	Star A322 Conductivity Portable Meter; 013010MD Conductivity Cell with 3 Meter Cable; 01100710 Conductivity 1413µS/cm Standard Pouches; 911110 Rinse Solution Pouches; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA3230	Star A323 RDO/DO Portable Meter
STARA3235	Star A323 RDO/DO Portable Meter; 087010MD RDO Optical DO Probe with 3 Meter Cable; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA3240	Star A324 pH/ISE Portable Meter
STARA3245	Star A324 pH/ISE Portable Meter; 8107UWMMD ROSS pH/ATC Triode with 3 Meter Cable; 910410 pH 4.01 Buffer Pouches; 910710 pH 7.00 Buffer Pouches; 911010 pH 10.01 Buffer Pouches; 810001 ROSS Electrode Storage Solution; 911110 Rinse Solution Pouches; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA3250	Star A325 pH/Conductivity Portable Meter
STARA3255	Star A325 pH/Conductivity Portable Meter; 8107UWMMD ROSS pH/ATC Triode with 3 Meter Cable; 013010MD Conductivity Cell with 3 Meter Cable; 910410 pH 4.01 Buffer Pouches; 910710 pH 7.00 Buffer Pouches; 911010 pH 10.01 Buffer Pouches; 810001 ROSS Electrode Storage Solution; 01100710 Conductivity 1413µS/cm Standard Pouches; 911110 Rinse Solution Pouches; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA3260	Star A326 pH/RDO/DO Portable Meter
STARA3265	Star A326 pH/RDO/DO Portable Meter; 8107UWMMD ROSS pH/ATC Triode with 3 Meter Cable; 087010MD RDO Optical DO Probe with 3 Meter Cable; 910410 pH 4.01 Buffer Pouches; 910710 pH 7.00 Buffer Pouches; 911010 pH 10.01 Buffer Pouches; 810001 ROSS Electrode Storage Solution; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor
STARA3290	Star A329 pH/ISE/Conductivity/RDO/DO Portable Meter
STARA3295	Star A329 pH/ISE/Conductivity/RDO/DO Portable Meter; 8107UWMMD ROSS pH/ATC Triode with 3 Meter Cable; 013010MD Conductivity Cell with 3 Meter Cable; 087010MD RDO Optical DO Probe with 3 Meter Cable; 910410 pH 4.01 Buffer Pouches; 910710 pH 7.00 Buffer Pouches; 911010 pH 10.01 Buffer Pouches; 810001 ROSS Electrode Storage Solution; 01100710 Conductivity 1413µS/cm Standard Pouches; 911110 Rinse Solution Pouches; STARA-CS Star A Carrying Case; STARA-AR Star A Meter Armor

Orion Star A Series Accessories and Electrodes		
Cat. No.	Description	
STARA-BEA	Orion Star A Series Electrode Arm and Holder (Attaches to base of meter or STARA-HB base)	
STARA-HB	Orion Star A Series Electrode Stand Base Only (Use when electrode arm is not attached to meter)	
STARA-CS	Orion Star A Series Portable Hard Carrying Case	
STARA-AR	Orion Star A Series Portable Meter Armor with Stand, includes one pH Electrode Holder with Storage Sleeve and one Conductivity Cell and DO Probe Holder	
STARA-ESPH	Orion Star A Series pH Electrode Holder for Meter Armor (requires pH storage sleeve, purchase separately)	
STARA-ESCD	Orion Star A Series Conductivity Cell and DO Probe Holder for Meter Armor	
1010003	Orion Star A Series Power Adapter for Benchtop and Portable Meters	
8102BNUWP	ROSS Ultra Glass Refillable pH Electrode	
8302BNUMD	ROSS Glass Refillable pH/ATC Triode	
8157BNUMD	ROSS Refillable Epoxy pH/ATC Triode	
8107UWMMD	ROSS Gel-filled Epoxy pH/ATC Triode with 3 Meter Cable	
927005MD	Epoxy Steel ATC Probe	
927007MD	Stainless Steel ATC Probe	
9179BNMD	Gel-filled Epoxy ORP/ATC Triode	
9180BNMD	Refillable Epoxy ORP/ATC Triode	
9512HPBNWP	High-Performance Ammonia Electrode	
9609BNWP	Fluoride Electrode	
8611BNWP	ROSS Sodium Electrode with Sodium Standards, Reagents and Solutions	
013005MD	DuraProbe Epoxy 4-Cell (K=0.475) Conductivity Cell	
013010MD	DuraProbe Epoxy 4-Cell (K=0.475) Conductivity Cell with 3 Meter Cable	
013020MD	DuraProbe Epoxy 4-Cell (K=0.475) Conductivity Cell with 6 Meter Cable	
013025MD	DuraProbe Epoxy 4-Cell (K=0.475) Conductivity Cell with 10 Meter Cable	
013016MD	Steel 2-Cell (K=0.1) Conductivity Cell with Detachable Flow Through Cell	
083005MD	Polarographic DO Probe with Calibration Sleeve	
083010MD	Polarographic DO Probe with Calibration Sleeve and 3 Meter Cable	
083025MD	Polarographic DO Probe with Calibration Sleeve and 10 Meter Cable	
086030MD	AUTO-STIR DO/BOD Probe	
087010MD	RDO Optical DO Probe with 3 Meter Cable	
087020MD	RDO Optical DO Probe with 6 Meter Cable	
087030MD	RDO Optical DO Probe with 10 Meter Cable	
096019	Stirrer Probe for Star A200 Series Benchtop Meters	

This page intentionally left blank.

Chapter 11 Meter Compliance

Notice of Compliance

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.

"This digital apparatus does not exceed the (Class A) limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications."

"Le present appareil numerique n' emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques (de la class A) prescrites dans le Reglement sur le brouillage radioelectrique edicte par le ministere des Communications du Canada."

WEEE Compliance



This product is required to comply with the European Union's Waste Electrical & Electronic Equipment (WEEE) Directive 2002/96/EC. It is marked with the symbol on the left.

Thermo Fisher Scientific has contracted with one or more recycling/disposal companies in each EU Member State and this product should be disposed of or recycled through them. Further information on compliance with these directives, the recyclers in your country, and information on Thermo Scientific Orion products that may assist the detection of substances subject to the RoHS Directive are available at www.thermoscientific.com.

Declaration of Conformity

Manufacturer: Thermo Fisher Scientific Inc.

Address:

Ayer Rajah Crescent Blk 55 #04-16/24 Singapore 139949 Singapore

Hereby declares that the following products:

Benchtop meters are rated 100 to 240 VAC, 50/60 Hz, 0.5A. Handheld meters use four non-rechargeable AA batteries.

Benchtop Meters

Orion Star A211 pH Orion Star A212 Conductivity Orion Star A213 RDO/DO Orion Star A214 pH/ISE Orion Star A215 pH/Conductivity Orion Star A216 pH/RDO/DO

Portable Meters

Orion Star A221 pH Orion Star A222 Conductivity Orion Star A223 RDO/DO Orion Star A321 pH Orion Star A322 Conductivity Orion Star A323 RDO/DO Orion Star A324 pH/ISE Orion Star A325 pH/Conductivity Orion Star A326 pH/RDO/DO Orion Star A329 pH/ISE/Conductivity/RDO/DO

Equipment Class:

Measurement, control and laboratory Orion Star A-series meters are EMC Class A

Conforms with the following directives and standards:

EN61326-1:2006	Electromagnetic Compatibility (EMC Directive) Electrical equipment for measurement, control and laboratory use - EMC requirements
EN61010-1:2001	Safety Standards
UL61010-1:2004	Safety requirements for electrical equipment for measurement
CAN/CSA C22.2 No. 61010-1-04	control and laboratory use - general requirements

Cheow Kwang Chan QA/Regulatory Manager Place and Date of Issue: June 15, 2011 Singapore

Meter Specifications

Meter Operating Conditions		
Operating Ambient Temperature	5 to 45 °C	
Operating Relative Humidity	5 to 85 %, non-condensing	
Storage Temperature	-20 to +60 °C	
Storage Relative Humidity	5 to 85 %, non-condensing	
Pollution	Degree 2	
Overvoltage	Category II	
Weight	Portable: 450g	
	Benchtop: 850g	
Size	Portable: 5.9cm (H) x 10.5cm (W) x 23.1cm (D)	
	Benchtop: 9.3cm (H) x 18.0cm (W) x 23.6cm (D)	
Regulatory and Safety	CE, TUV 3-1, FCC Class A	
Power Rating	DC Input: 9 VDC 1A	
	Battery: 4 x AA	
Shock and Vibration	Vibration: shipping/handling per ISTA #1A.	
	Shock: drop test in packaging per ISTA #1A	
Enclosure (designed to meet)	Portable: IP67	
	Benchtop: IP54	
Warranty	3 year meter replacement	

Universal Power Adapter Operating Conditions		
Operating Ambient Temperature	0 to 50 °C	
Operating Relative Humidity	0 to 90 %, non-condensing	
Storage Temperature	-20 to +75 °C	
Storage Relative Humidity	0 to 90 %, non-condensing	
Pollution	Degree 2	
Overvoltage	Category II	

Meter Parameter Specifications		
рН		
Range	-2.000 to 20.000	
Resolution	0.1, 0.01, 0.001	
Relative Accuracy	± 0.002	
Calibration Points	Up to 5	
Calibration Editing	Yes	
mV/RmV		
Range	± 2000.0 mV	
Resolution	0.1, 1	
Relative Accuracy	±2%	
E _H ORP Mode	Yes	

ISE		
Range	0 to 19999	
Resolution	Up to 3 significant digits	
Relative Accuracy	\pm 0.2 mV or \pm 0.05 % of reading, whichever is greater	
Units	ppm, M, mg/L, %, ppb, none	
Calibration Points	Up to 5	
Calibration Editing	Yes	
Calibration Features	Linear point to point, non-linear selectable auto-blank, low concentration range stability	
Temperature Measurement		
Range	0 to 50°C	
Resolution	0.1	
Relative Accuracy	± 0.1	
Offset Calibration	1 point	
Data Logging		
Number of Points	Star A214: 2000 with time and date stamp	
	Star A324: 5000 with time and date stamp	
Log Function	Manual, Ready (AUTO-READ), Timed	
Log Edit	Delete individual points, group of points or all	
Inputs		
pH or Ion Selective Electrode	BNC, reference pin	
ATC Probe	8-pin MiniDIN	
Output	RS232, USB	
Power		
AC Adapter	Universal, 110 - 240 VAC (included with Star A214)	
Battery Power	Four Alkaline AA (included with Star A324)	
Battery Life	2000 hours	

Appendix 1 Advanced Meters Features

Automatic pH Buffer Recognition Feature

The Orion Star A200 and Star A300 series pH meters are capable of automatically recognizing pH 1.68, 4.01, 7.00, 10.01 and 12.46 buffers or pH 1.68, 4.01, 6.86, and 9.18 buffers during a pH calibration, depending on the pH buffer set that is selected in the setup menu. During a calibration, the meter uses the selected buffer set and the raw mV reading of the pH electrode in the buffer to recognize and display the buffer value at the measured temperature. The raw mV reading of the pH electrode in the buffer must be about \pm 30 mV from the theoretical mV reading of the buffer to recognize the buffer.

USA pH Buffer Set		DIN pH Buff	er Set
Buffer	mV Range	Buffer	mV Range
1.68	+285 to +345 mV	1.68	+285 to +345 mV
4.01	+207 to +147 mV	4.01	+207 to +147 mV
7.00	- 30 to + 30 mV	6.86	+38 to -22 mV
10.01	-207 to -147 mV	9.18	-99 to -159 mV
12.46	-293 to -353 mV		

Testing a pH Electrode for Automatic Buffer Recognition

To verify that the raw mV reading of the pH electrode in use is \pm 30 mV from the theoretical mV reading of the buffer, and therefore verify that the pH electrode in use is capable of performing automatic buffer recognition, perform the following procedure.

- 1. Set the measurement mode to mV. Prepare the pH electrode according to the instructions in the pH electrode user guide.
- 2. Rinse the pH electrode with distilled water, blot it dry with a lint-free tissue and place the pH electrode into a pH 4.01 buffer at approximately 25 °C.
- Wait for the measurement to stabilize and record the mV value of the pH 4.01 buffer when the meter indicates that the measurement is stable. The read type selected in the setup menu will determine how the mV measurements are displayed by the meter.
- 4. Remove the pH electrode from the pH 4.01 buffer.
- 5. Rinse the pH electrode with distilled water, blot it dry with a lint-free tissue and place the pH electrode into a pH 7.00 buffer at approximately 25 °C.
- 6. Wait for the measurement to stabilize and record the mV value of the pH 7.00 buffer when the meter indicates that the measurement is stable.
- 7. The mV reading of the pH electrode in pH 4.01 buffer should be in the range of +207 to +147 mV and the mV reading of the pH electrode in pH 7.00 buffer should be in the range of -30 to +30 mV. If the mV readings of the pH electrode are in the correct ranges, the pH electrode is capable of performing automatic buffer recognition. If the mV readings of the pH electrode are not in the correct ranges, the values of the pH buffers will need to be manually entered during a pH calibration.

Electrode Condition Icon

The electrode condition icon indicates the performance of the pH electrode, based on the last saved calibration and electrode measurement stability.

lcon	pH Electrode Definition of Icon
ſ	Electrode condition is good and the electrode slope is 90 to 110 %.
ſ	Electrode condition is fair and the electrode slope is 80 to 120 %.
£	Electrode condition is bad and the electrode slope is less than 80 % or greater than 120 %. Consult the electrode user guide for instructions on how to clean, condition and troubleshoot the electrode.

Multipoint Calibration Curve Feature

The Orion Star A200 and Star A300 series pH and ISE meters utilize a point-to-point scheme for multipoint calibrations in the pH and ISE modes. In this technique, straight line segments are drawn between each successive pair of calibration points. Separate slope and Eo values are calculated using the adjacent pair of data points. For example, in a five point calibration, four slopes and five Eo values are calculated to correspond to the four line segments that connect the data. pH or concentration values for samples are calculated according to the segment that their potential values fall into. Those above or below the range of calibration are calculated by extrapolation from the top or bottom most segment.

The displayed slope is an average slope of the separate segments. The slope may be outside the range normally expected for an electrode. For example, if the slope of one segment is low, then the average will be lower than theoretical, even though the response may be Nernstian over most of the range.

The figure below is an example of a typical calibration curve using this method.



Automatic Blank (Non-linear) Correction Feature

The Orion Star A200 and Star A300 series ISE meters have a feature known as automatic blank correction. In this technique, the meter decides whether blank correction is the best measurement strategy by analyzing the electrode response during a multipoint calibration. A separate blank does not have to be run. Graphically, automatic blank correction is equivalent to drawing a smooth curve through the lowest three points of the multipoint calibration and extrapolating to zero concentration based on the assumption of Nernstian electrode behavior.

Multipoint calibrations at the lower limit of detection are desirable when the response of an ion selective electrode is nonlinear and cannot be characterized with a one or two point calibration. This is usually seen as a low electrode slope. Generally, the electrode is behaving in a Nernstian manner but the effect of a blank is being observed. See the figure below.



This blank may be a true reagent blank, traces of analyte ion in the reagents or it may be the "mud" value of the electrode. It could also be an interference in the reagents that becomes apparent at low levels of analyte ion, or it could be any combination of these effects. The expanded version of the Nernst equation traditionally used for blank correction is as follows:

E = Eo + S * log (C + b) where b is the blank

In a multi-point calibration, a set of equations is generated and the relationship between them evaluated. For example the equations generated in a three point calibration would be as follows:

E1 = Eo + S * log (C1 + b)E2 = Eo + S x log (C2 + b)E3 = Eo + S x log (C3 + b)

The meter evaluates the relationships between the three potentials E1, E2 and E3 and the three concentrations C1, C2 and C3. If the relationships indicate that blank correction is desired, a blank will automatically be calculated and the non-linearity will be corrected for in a Nernstian manner. If the appropriate conditions are not met, the blank is set at zero and each segment of the multipoint calibration is treated independently.

When all three of the following conditions are met, blank correction is invoked.

- 1. The concentration of the first standard is zero, or the slope of the electrode between the first and second standards is less than the slope between the second and third.
- 2. Potential differences between points are significant. For example, E3 E1 > 10 mV
- The blank correction algorithm converges at reasonable blank and slope values. Conditions in steps 1 and 2 prevent failure to converge in most situations. However, the slope will attain any value necessary for convergence to a calculated blank value of 3 x C3.

When blank correction is implemented, the slope value for the electrode may be outside the range of values normally considered acceptable during an ordinary calibration. For best results, calibration standards should be close in range to the expected sample concentrations and should bracket the expected sample concentration. When conditions 1, 2 and 3 are not met, the calibration data is handled by the multipoint calibration method described earlier.

In calibrations with more than three points, a combination of methods is utilized. Automatic blank correction is used if the lowest three points satisfy the criteria and multipoint calibration is used for the other points. The slope displayed after calibration is an average of the slope calculated in the automatic blank correction algorithm and the slope(s) for each additional segment. This page intentionally left blank.

Water Analysis Instruments

North America

166 Cummings Center Beverly, MA 01915 USA Toll Free: 1-800-225-1480 Tel: 1-978-232-6000 info.water@thermo.com

Netherlands

Tel: (31) 033-2463887 info.water.uk@thermo.com

India Tel: (91) 22-4157-8800 wai.asia@thermofisher.com

Japan Tel: (81) 045-453-9175 wai.asia@thermofisher.com

China Tel: (86) 21-68654588 wai.asi@thermofisher.com

Singapore Tel: (65) 6778-6876 wai.asia@thermofisher.com

Australia

Tel: (613) 9757-4300 in Australia (1300) 735-296 InfoWaterAU@thermofisher.com www.thermoscientific.com/water

© 2011 Thermo Fisher Scientific Inc. All rights reserved.



68X576704 RevA 10-11

