

# LDARtools

1102 Dickinson Ave  
Dickinson, TX 77539  
Phone: 877-788-1110 ext. 1  
Fax: 866-385-9142  
www.ldartools.com

## phx42 Backpack Modification

1. Open an empty backpack as shown:



2. With a pair of scissors, make a cut in the liner straight up from (A) to the center of the strap (B).

Now, you can insert the probe handle through that hole **WITHOUT** disconnecting the probe assembly, the probe tip filter, or the probe tip.



3. Thread the probe assembly through the hole and down the strap and close the zipper enough to keep the hose in place but not restrict the Tech's movement.



The probe hose is now protected!

