

Grundfos Redi-Flo4

Part Numbers

Position Number	Part Numbers	Description	
1	085052	Upper Chamber	
1b	055006	Discharge 1 1/2" NPT	
	085022	Discharge 1" NPT	
	085047	Discharge 1 1/4" NPT	
3a	080041	Valve Seat Support	
7	91121961	Seal Ring (old p/n # 050005)	
	91121960	Bearing (old p/n # 050004)	
9	055017	Int. Chamber 25E	
	095065	Int. Chamber 5E, 10E, 16E	
10	085030	Lower Chamber with Screen	
12	ID7253	Lock Nut for Shaft	
13	055001	Impeller 25E	
	085023	Impeller 5E	
	085048	Impeller 10E	
	085050	Impeller 16E	
14	085020	Inlet	
16	086203	Shaft 5E3	
	086204	Shaft 16E4 & 25E4	
	086205	Shaft 5E5, 10E5	
	086206	Shaft 25E6	
	086207	Shaft 16E7	
	086208	Shaft 5E8, 10E8 & 25E8	
	086209	Shaft 16E9	
	086211	Shaft 10E11	
	086212	Shaft 5E12	
	086213	Shaft 16E13	
	086214	Shaft 10E14	
	086219	Shaft 10E19	
	086221	Shaft 5E21	
	086225	Shaft 5E25	
	086217	Shaft 5E17	
	17	089203	Strap 5E3
		089204	Strap 16E4 & 25E4
089205		Strap 5E5, 10E5	
089206		Strap 25E6	
089207		Strap 16E7	
089208		Strap 5E8, 10E8 & 25E8	
089209		Strap 16E9	
089211		Strap 10E11	
089212		Strap 5E12	
089213		Strap 16E13	
089214		Strap 10E14	
089217		Strap 5E17	
18	089219	Strap 10E19	
	089221	Strap 5E21	
	089225	Strap 5E25	
	084603	Cable Guard 5E3	
	084604	Cable Guard 16E4 & 25E4	
	084605	Cable Guard 5E5, 10E5	
	084606	Cable Guard 25E6	
	084607	Cable Guard 16E7	
	084608	Cable Guard 5E, 10 & 25E8	
	084609	Cable Guard 16E9	
	084611	Cable Guard 10E11	
	084612	Cable Guard 5E12	
084613	Cable Guard 16E13		
084614	Cable Guard 10E14		
084617	Cable Guard 5E17		
084619	Cable Guard 10E19		
084621	Cable Guard 5E21		
084625	Cable Guard 5E25		
19	ID3943	Bolt for Straps	
64	080051	Priming Inducer	
71	410026	Washer	
84	100081	Cover Plate	
NS	090032	Washer	
NS	100081	Cover Plate	

