

Chemical Compatibility Table

For All Non-Metals

R = Resistant
 A = Excellent – No effect
 B = Good – Minor effect
 C = Fair – Moderate effect

U = Unsatisfactory
 X = Conflicting Data
 – = No Data Available

*No corrosion rate reported

For Metals

E <2 mils Penetration/Year
 G <20 mils Penetration/Year
 S <50 mils Penetration/Year
 U >50 mils Penetration/Year
 (1 mil = .001 inch)

A = Excellent – No effect*
 B = Good – Minor effect*
 C = Fair – Moderate effect*

REFERENCE PAGES

	Plastic									Elastopolymer							Metals											
	ABS	Acetal (Delrin)	CPVC	FEP	Nylon 6, 66	HDPE	Polypropylene	PTFE (Teflon®)	PVC Type I	PVC Type II	PVDF (Kynar)	EPDM	Kel-F	Neoprene	Nitrile Buna-N	Polyurethane	Silicone	Tygon®	Viton-A	Ceramic	Silica	304 Stainless	316 Stainless	Carbon Steel	Hastelloy-C	Aluminum	Brass	Copper
Acetaldehyde	U	A	U	R	U	U	A	A	U	U	X	A	A	C	U	U	A	U	U	-	R	E	E	G	E	G	U	U
Acetamide	-	A	-	R	R	R	A	A	U	-	C	A	A	B	A	U	B	U	B	-	-	G	G	-	-	G	-	-
Acetate Solvent	U	-	U	R	R	R	B	A	U	U	A	A	A	C	U	-	A	U	U	-	-	E	E	G	E	E	S	G
Acetic Acid 10%	X	X	C	R	U	R	B	A	U	-	C	A	A	C	C	-	C	U	R	A	R	E	E	U	E	G	U	G
Acetic Acid, Glacial	U	U	U	R	U	R	A	A	U	U	B	U	A	X	X	U	B	U	U	A	R	E	E	U	E	E	U	U
Acetone	U	A	U	R	R	R	A	A	U	U	U	A	A	U	U	U	B	U	U	A	R	E	E	G	E	E	G	E
Acetonitrile	U	-	-	R	R	-	R	R	-	-	R	R	-	-	-	-	-	-	-	-	-	G	G	G	-	E	G	G
Acetophenone	U	-	-	R	R	U	R	R	U	U	R	R	-	U	U	-	-	-	U	-	-	G	G	G	G	G	G	G
Acetyl Chloride	U	-	U	R	U	U	U	A	U	U	R	U	-	U	U	U	-	-	R	-	R	G	G	G	-	U	U	U
Acetylene	R	-	R	R	R	-	R	R	R	R	R	R	-	R	R	-	-	-	R	-	-	E	E	G	G	E	U	U
Acrylonitrile	U	-	X	R	R	R	A	A	X	U	A	X	-	C	U	-	U	-	U	-	-	G	G	G	G	E	G	G
Adipic Acid	R	-	A	R	-	R	B	A	R	R	A	A	A	B	X	-	U	-	X	-	-	G	G	G	E	G	-	G
Aldrin (1 oz./gal.)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	E	E	G	-	E	-	-
Allyl Alcohol	U	-	R	R	R	R	R	R	R	R	R	R	-	R	R	-	-	-	R	-	-	E	E	G	G	G	G	E
Allyl Chloride	U	-	U	R	-	R	R	R	U	U	R	U	-	U	U	-	-	-	-	-	R	G	E	U	-	U	-	-
Ammonium Acetate	-	-	A	R	A	-	A	A	R	R	R	A	-	A	B	-	-	A	A	-	-	G	G	-	-	G	U	U
Ammonium Oxalate 10%	-	-	-	R	-	-	R	R	R	-	-	R	-	-	-	-	-	-	-	-	-	G	G	U	E	E	-	U
Amyl Acetate	U	B	U	R	R	R	X	A	U	U	A	A	A	U	U	U	U	U	U	A	R	E	E	G	E	E	E	G
Amyl Alcohol	R	A	A	R	A	R	B	A	R	U	A	A	A	A	B	U	U	A	B	A	R	G	G	G	G	G	G	G
Amyl Chloride	U	-	U	R	U	U	U	R	U	U	U	R	-	U	U	-	-	-	R	-	-	G	G	U	E	U	G	G
Aniline	U	A	X	R	X	R	X	A	U	U	A	X	A	U	U	U	U	C	B	A	R	E	E	G	G	G	U	U
Aniline Hydrochloride	U	-	U	R	U	U	X	A	X	U	A	B	-	U	U	-	U	U	A	-	R	U	U	U	U	U	U	G
Antifreeze	B	U	A	-	U	-	U	-	A	-	-	A	-	C	A	-	C	B	A	-	-	-	A	-	-	A	-	-
Aroclor 1248	-	-	-	R	A	U	U	A	-	-	-	B	A	U	X	-	B	-	A	-	-	G	G	G	E	E	E	E
Asphalt	-	B	X	R	A	R	B	A	A	-	A	U	A	U	X	-	U	-	A	-	-	G	G	G	-	E	E	E
Benzaldehyde	X	A	U	R	A	U	X	A	U	U	A	A	A	U	U	U	U	U	U	A	R	G	G	U	G	G	G	G
Benzene	U	A	U	R	A	U	X	A	U	U	A	U	B	U	U	U	U	C	A	A	R	G	G	G	G	E	G	G
Benzo Sulfonic Acid 10%	R	-	R	R	U	R	R	R	R	R	R	U	-	R	U	U	-	-	R	-	R	G	G	U	G	U	G	-
Benzyl Alcohol	U	A	X	R	B	U	A	A	U	U	A	B	A	X	X	U	-	U	A	A	R	E	E	G	G	G	G	E
Benzoic Acid	R	B	A	R	X	B	R	A	R	R	A	U	A	B	U	U	B	A	A	A	R	G	G	U	E	G	G	G
Benzol	U	A	U	R	X	U	U	A	U	U	A	U	A	U	U	U	U	C	A	A	R	G	G	G	G	E	G	G
Benzonitrile	-	-	-	R	R	A	-	A	-	-	-	-	A	-	-	-	A	-	-	-	-	U	U	-	C	-	-	-
Benzyl Chloride	U	A	U	R	R	-	C	R	R	-	R	U	-	U	U	-	U	-	A	-	-	G	G	U	-	U	U	U
Bromobenzene	-	-	-	R	-	-	U	R	-	-	R	U	-	U	U	-	-	-	R	-	-	-	-	-	-	-	-	-
Butadiene	U	A	A	R	R	U	U	A	R	U	A	X	A	B	X	U	U	-	B	-	-	G	G	G	G	G	G	G

	Plastic									Elastopolymer							Metals											
	ABS	Acetal (Delrin)	CPVC	FEP	Nylon 6, 66	HDPE	Polypropylene	PTFE (Teflon®)	PVC Type I	PVC Type II	PVDF (Kynar)	EPDM	Kel-F	Neoprene	Nitrile Buna-N	Polyurethane	Silicone	Tygon®	Viton-A	Ceramic	Silica	304 Stainless	316 Stainless	Carbon Steel	Hastelloy-C	Aluminum	Brass	Copper
Butane	B	A	C	R	R	U	U	A	R	R	A	U	A	A	A	R	U	C	A	-	-	G	G	E	G	G	G	G
Butyl Alcohol	U	A	A	R	B	B	R	A	R	U	A	A	A	X	-	B	B	A	-	R	F	F	G	G	F	G	G	
n-Butyl Amine	-	X	U	R	R	U	U	A	U	U	X	-	U	U	R	-	B	U	U	-	-	-	G	G	G	G	-	-
Butyl Ether	-	U	U	R	A	-	-	A	R	-	A	U	A	U	B	-	U	A	U	-	-	-	F	E	-	F	-	-
Butyl Phenol	U	-	U	R	-	-	U	R	U	U	R	-	-	U	-	-	-	U	-	-	G	F	-	G	G	-	-	
Butyl Phthalate	-	-	U	R	R	-	R	R	R	-	R	B	A	D	U	-	A	-	C	-	-	G	G	-	G	U	G	G
Butylacetate	U	A	X	R	A	R	X	A	U	U	B	B	A	X	U	-	U	U	U	-	R	G	G	G	G	E	G	G
Butyric Acid	U	A	U	R	U	U	R	R	U	U	A	B	A	U	U	-	U	U	B	-	R	G	G	U	E	G	G	G
Carbon Tetrachloride	U	B	U	R	X	U	U	R	U	U	R	U	A	U	U	U	U	B	A	A	R	E	E	G	E	U	G	E
Carbonic Acid	R	B	A	R	R	R	A	A	R	R	A	B	A	X	X	R	A	-	A	A	-	G	G	G	E	E	G	G
Chloroacetic Acid	U	U	U	R	U	U	C	A	R	R	A	B	A	U	U	U	A	U	-	-	U	U	U	E	U	U	U	
Chlorobenzene	U	X	U	R	R	U	U	B	U	U	A	U	A	U	U	-	U	A	A	A	R	G	G	G	E	G	G	G
Chlorobromomethane	-	-	-	-	C	-	A	A	U	-	-	B	-	U	U	-	U	-	A	A	-	-	-	-	-	B	-	-
Chlordane (¼ lb./gal.)	U	-	-	-	-	-	-	R	-	-	-	U	-	C	B	-	U	-	A	-	-	G	G	G	-	-	-	-
Chloroethane	U	A	U	R	R	R	X	A	U	U	A	X	A	U	U	-	U	-	B	-	-	G	G	G	-	-	-	G
Chloroform	U	A	U	R	R	U	X	A	U	U	A	U	B	U	U	U	U	B	A	A	R	E	E	U	G	G	G	G
Chloronaphthalene	U	-	-	-	-	-	-	R	-	-	-	-	-	U	U	-	-	-	-	-	-	-	G	-	E	U	-	-
Chlorophenol 5% (aq.)	-	R	U	R	U	-	-	R	U	U	R	-	-	-	-	-	-	-	-	-	-	G	G	S	E	-	-	-
Citric Acid	U	B	B	R	R	A	A	A	R	-	A	A	A	A	-	A	-	A	A	R	E	E	U	E	E	-	E	-
Cresol	U	U	U	R	U	U	U	R	X	U	R	U	A	U	U	U	U	X	-	R	E	G	G	G	G	-	-	-
Cresylic Acid 50%	U	U	U	R	U	R	X	R	R	R	R	X	-	U	U	U	U	-	A	-	-	G	G	G	G	G	-	-
Crude Oil	R	R	R	R	R	U	R	U	U	U	U	U	-	U	R	R	-	-	R	-	-	E	E	G	E	E	G	G
Cyclohexane	R	A	U	R	R	R	U	A	X	-	R	U	A	U	B	R	U	U	A	-	-	G	G	G	G	G	G	G
Cyclohexanone	U	A	U	R	R	U	U	A	U	U	R	B	U	U	U	-	U	U	U	A	-	G	G	U	G	G	G	G
DDT 5%	-	-	U	-	-	-	-	-	U	U	-	-	-	-	-	-	-	-	-	-	-	E	E	G	-	E	-	-
Detergents (general)	B	A	A	R	R	R	A	A	R	R	A	A	A	B	A	-	A	A	A	A	-	E	G	G	E	G	G	E
Diacetone Alcohol	-	A	U	R	R	R	R	A	R	-	A	A	B	U	U	-	U	B	U	-	-	G	G	G	E	E	E	E
Dibutyl Phthalate	U	-	U	R	R	U	R	R	U	U	U	R	-	U	U	U	-	-	U	-	-	G	G	G	G	G	G	G
Dichlorobenzene	U	-	U	R	X	U	C	A	U	U	A	U	-	U	U	-	U	-	C	-	-	-	G	-	E	G	-	-
Dichloroethane	U	A	U	R	R	R	X	A	U	U	A	U	A	U	U	-	-	U	C	A	R	G	G	G	G	G	G	-
Dichloroethylene	U	-	-	R	R	-	R	R	U	U	R	U	-	U	U	-	-	-	R	-	-	G	G	-	G	G	-	-
Dichlorofluoromethane	-	-	-	R	-	-	-	R	U	U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Diesel Fuel	-	A	A	R	R	R	A	A	R	-	A	U	A	B	A	-	U	-	A	-	-	E	E	G	G	E	E	-
Diethanolamine	-	-	-	R	R	-	R	R	U	U	U	-	-	R	-	-	-	-	-	-	-	E	E	E	E	E	-	G
Diethyl Amine	U	B	U	R	R	U	A	X	U	-	X	B	A	A	C	-	B	C	A	-	-	G	G	U	-	G	-	-
Diethyl Ether	U	R	U	R	R	U	R	A	U	U	R	U	C	U	U	-	U	-	U	-	-	G	G	G	G	G	G	G
Diethyl Phthalate	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Diethylene Glycol	B	A	A	R	R	R	A	A	X	-	A	A	-	A	A	-	B	C	A	-	-	E	E	E	G	G	-	G
Dimethyl Aniline	U	U	U	R	R	-	X	A	U	U	A	B	A	U	U	-	U	U	U	-	-	B	B	-	B	A	-	-
Dimethyl Ether	-	-	-	R	-	-	-	R	-	-	-	-	-	U	R	-	-	-	-	-	-	G	G	-	G	-	G	G
Dimethyl Formamide	U	X	U	R	R	R	A	X	U	U	U	X	A	X	U	-	C	U	X	-	-	-	G	U	-	E	-	-
Dimethyl Phthalate	U	-	-	R	R	-	R	R	U	U	R	-	-	U	U	-	-	-	R	-	-	E	E	E	-	E	-	-
Dimethyl Sulfoxide	-	R	U	R	R	R	R	R	U	-	U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Dinitrotoluene	-	-	-	-	-	-	-	R	-	-	-	U	-	U	U	-	U	-	X	-	-	G	G	-	-	-	-	-
Diocetyl Phthalate	U	-	U	R	R	U	U	R	U	U	R	R	-	U	U	U	-	-	R	-	-	G	G	G	-	E	-	-
Dioxane	U	R	-	R	R	U	R	R	U	-	U	U	-	U	U	-	-	-	U	-	-	G	G	G	G	G	G	G
Diphenyl	-	-	-	R	R	-	U	A	U	-	-	U	-	B	U	R	U	-	A	-	-	G	G	G	G	G	G	G
Diphenyl Oxide	-	U	-	-	-	-	U	A	U	-	B	U	-	U	A	-	C	U	A	-	-	B	A	-	B	B	-	A
Esters (general)	-	-	U	R	R	-	-	R	U	U	R	-	-	-	-	-	-	-	-	-	-	-	G	-	-	-	-	-

REFERENCE PAGES

	Plastic									Elastopolymer							Metals											
	ABS	Acetal (Delrin)	CPVC	FEP	Nylon 6, 66	HDPE	Polypropylene	PTFE (Teflon®)	PVC Type I	PVC Type II	PVDF (Kynar)	EPDM	Kel-F	Neoprene	Nitrile Buna-N	Polyurethane	Silicone	Tygon®	Viton-A	Ceramic	Silica	304 Stainless	316 Stainless	Carbon Steel	Hastelloy-C	Aluminum	Brass	Copper
Ethane	-	A	A	-	U	-	U	A	A	-	A	U	-	B	A	-	U	A	A	-	-	A	A	-	-	-	-	A
Ethanolamine	-	U	U	R	R	-	X	A	U	-	X	B	U	B	B	-	B	-	U	A	-	E	E	G	G	G	-	-
Ethers (general)	U	A	U	-	R	U	U	A	U	U	R	C	B	U	X	-	U	C	X	-	R	E	E	G	G	G	G	G
Ethyl Acetate	U	A	U	R	R	R	A	A	U	U	X	B	A	U	U	U	B	U	U	A	R	G	G	G	G	-	G	G
Ethyl Alcohol	B	A	B	R	R	R	A	A	R	R	R	A	B	A	C	U	B	C	A	A	R	G	G	G	E	E	G	G
Ethyl Benzene	-	R	-	R	-	U	U	R	U	U	R	U	-	U	U	-	-	-	R	-	-	S	G	U	E	G	-	-
Ethyl Benzoate	U	-	U	-	-	U	B	A	U	-	U	-	-	U	U	-	U	U	A	-	-	-	-	-	-	-	-	-
Ethyl Chloride	U	R	U	R	R	U	U	R	U	U	R	R	-	U	R	U	-	-	B	-	R	E	E	G	G	-	-	G
Ethyl Ether	U	A	U	R	R	U	U	A	U	U	R	U	A	U	X	U	U	-	U	-	R	G	G	G	G	G	G	G
Ethyl Sulfate	-	-	-	-	-	-	-	A	-	-	-	-	A	-	A	-	-	-	A	-	-	U	U	-	-	-	-	B
Ethylene Bromide	U	-	U	R	R	U	U	A	U	U	A	X	B	X	U	-	U	U	A	-	-	E	E	-	E	-	-	-
Ethylene Chloride	U	A	U	R	R	R	X	A	U	U	A	X	A	U	U	-	U	-	B	-	-	G	G	G	-	-	-	G
Ethylene Chlorohydrin	U	U	U	R	U	U	X	A	U	U	A	B	-	X	U	U	C	U	A	-	-	G	G	G	G	G	G	G
Ethylene Diamine	U	X	U	R	U	-	R	A	U	U	B	A	U	X	A	-	A	-	B	-	-	G	G	G	U	G	U	U
Ethylene Dibromide	-	-	-	R	-	-	R	R	-	-	R	-	-	-	-	-	-	-	-	-	-	-	G	-	G	-	G	-
Ethylene Glycol	A	B	A	R	R	R	A	A	R	R	A	A	A	A	R	A	B	R	A	A	-	G	G	G	E	E	G	G
Ethylene Oxide	U	U	X	R	R	R	U	A	U	U	A	X	C	U	U	U	U	-	U	-	R	G	G	G	E	E	U	-
Formaldehyde 100%	B	A	A	-	U	-	C	A	A	-	A	A	A	C	C	-	B	B	U	-	-	C	A	-	A	A	-	A
Formaldehyde 37%	A	A	A	R	R	R	A	A	R	R	A	A	A	B	X	U	-	-	R	-	R	E	E	U	G	G	E	G
Formic Acid 5%	-	U	R	R	U	R	R	R	R	-	R	R	-	R	U	-	-	-	R	-	-	G	E	-	E	U	S	E
Fuel Oils	U	A	-	R	R	R	A	B	R	R	B	U	A	B	X	R	U	A	A	-	-	G	G	G	G	G	G	G
Gasoline (high-aromatic)	U	B	A	-	-	-	A	B	A	-	A	U	A	A	A	-	U	A	A	A	-	A	A	-	A	U	-	-
Gasoline (leaded)	U	A	U	R	R	U	X	A	R	-	A	U	A	B	A	R	U	C	A	A	-	G	G	G	E	G	G	G
Gasoline (unleaded)	U	A	X	R	R	U	X	A	R	-	A	U	A	B	A	R	U	C	A	-	-	G	G	G	E	G	G	G
Glycolic Acid	B	A	A	R	-	R	A	A	R	R	B	A	B	A	A	-	A	A	A	-	-	G	G	U	G	G	-	-
Heptane	X	A	A	R	R	R	C	A	R	R	A	U	A	B	A	U	U	B	A	-	-	G	G	G	E	G	G	G
Hexachloroethane	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	-	-	-	-	-	-	G	G	-	G	G	S	G
Hexamine	-	-	-	R	-	-	-	R	-	-	-	-	-	-	-	-	-	-	-	-	-	E	E	-	E	E	G	-
Hexane	U	A	B	R	R	U	B	A	R	R	A	U	A	B	A	R	U	U	A	-	-	E	E	G	E	G	G	-
Hexyl Alcohol	-	A	-	-	A	-	-	A	A	-	-	C	-	A	A	-	B	A	C	-	-	A	A	-	A	A	-	-
Hydraulic Oil (petro.)	-	B	-	-	A	-	U	A	A	-	A	U	-	A	A	-	B	A	A	-	-	A	A	-	A	A	A	A
Hydraulic Oil (synthetic)	-	-	-	-	A	-	U	A	A	-	A	A	-	A	U	-	B	A	A	-	-	A	A	-	A	A	A	A
Hydrazine	-	B	U	-	-	U	C	C	-	-	A	A	-	B	B	-	B	-	A	-	-	A	A	-	-	-	-	A
Hydrogen Peroxide (dilute)	R	R	U	R	R	R	R	R	R	-	R	R	-	U	R	-	-	-	R	-	-	G	G	U	E	E	U	U
Hydroquinone	X	A	A	R	U	-	A	A	R	R	R	U	-	A	X	-	-	-	B	-	-	G	G	G	G	G	G	-
Hydroxyacetic Acid 70%	-	A	A	-	-	-	-	A	U	-	A	A	-	A	A	-	-	-	A	-	-	-	-	-	-	-	-	-
Iodoform	-	-	-	R	-	-	R	C	-	-	C	A	-	A	U	-	-	C	R	-	R	E	E	U	U	G	-	G
Isobutyl Alcohol	B	A	-	-	A	-	A	A	A	-	-	A	-	A	B	-	A	A	A	-	-	-	-	-	-	-	-	-
Isooctane	-	-	-	-	A	B	A	A	A	-	A	U	A	B	A	-	U	A	A	-	-	A	A	-	-	A	A	-
Isopropyl Acetate	U	U	U	R	R	R	B	A	U	U	X	B	-	U	U	-	U	-	U	-	-	E	G	E	G	G	-	-
Isopropyl Alcohol	R	A	C	R	U	R	A	A	R	R	R	A	-	B	B	U	A	A	A	A	-	G	G	G	G	G	G	G
Isopropyl Ether	-	U	R	R	R	-	X	A	R	R	X	U	A	U	B	R	U	A	U	-	-	E	G	-	-	-	G	G
Isotane	-	-	-	-	U	-	U	-	A	-	A	-	-	U	A	-	-	-	-	A	-	-	-	-	-	U	-	-
Jet Fuel JP-4, JP-5	-	A	R	R	R	-	A	A	R	R	A	U	A	U	A	U	U	A	A	-	-	G	G	G	E	G	E	-
Kerosene	X	A	R	R	R	R	R	A	R	R	A	U	A	A	A	U	U	U	A	A	-	G	G	G	G	G	G	G
Lacquer Thinners	A	U	-	-	A	-	U	A	U	-	-	U	-	U	U	-	U	U	U	-	-	-	G	-	-	G	-	-
Lacquers	A	U	-	-	A	-	U	A	U	-	U	U	-	U	U	-	U	A	U	-	-	E	E	-	-	-	-	-
Lactic Acid	U	B	A	R	R	-	B	A	R	R	B	A	A	A	X	-	A	A	A	A	-	G	G	U	G	G	G	G
Lead Acetate	B	B	A	R	R	R	A	A	R	R	A	A	A	A	B	-	A	B	U	A	-	G	G	U	G	U	U	G

	Plastic										Elastopolymer							Metals										
	ABS	Acetal (Delrin)	CPVC	FEP	Nylon 6, 66	HDPE	Polypropylene	PTFE (Teflon®)	PVC Type I	PVC Type II	PVDF (Kynar)	EPDM	Kel-F	Neoprene	Nitrile Buna-N	Polyurethane	Silicone	Tygon®	Viton-A	Ceramic	Silica	304 Stainless	316 Stainless	Carbon Steel	Hastelloy-C	Aluminum	Brass	Copper
Linoleic Acid	A	B	A	R	U	U	B	A	R	R	A	U	-	U	B	-	B	A	B	-	-	G	G	U	G	G	U	U
Maleic Acid	R	A	A	R	X	R	R	A	R	R	A	X	-	U	U	-	-	C	A	-	R	G	G	U	G	-	G	-
Malic Acid	R	A	R	R	X	R	A	A	R	R	A	U	-	X	A	-	B	A	A	-	-	E	E	U	G	G	-	U
Melamine	-	A	A	-	A	-	A	A	U	-	-	A	-	U	C	-	C	U	A	-	-	-	U	-	-	-	-	-
Methane	-	A	-	R	R	-	A	A	R	R	A	X	-	B	A	-	U	-	A	-	-	E	E	G	E	E	E	G
Methyl Acetate	U	X	U	R	R	R	X	A	U	U	B	X	A	X	U	-	U	A	U	-	-	G	G	S	E	G	-	-
Methyl Acetone	-	U	-	-	A	-	-	A	U	-	U	A	-	U	U	-	-	A	U	-	-	A	A	-	-	A	A	-
Methyl Acylate	-	B	-	-	-	-	U	-	-	-	B	B	-	B	U	-	U	-	U	-	-	A	-	-	-	-	-	-
Methyl Alcohol	U	A	A	R	R	R	A	A	R	R	A	A	A	A	A	U	A	A	U	A	R	G	G	G	E	G	G	G
Methyl Alcohol 10%	U	A	A	-	B	B	A	A	-	-	A	A	A	A	A	-	A	A	A	A	-	-	-	-	-	-	-	-
Methyl Amide	U	U	-	-	-	-	A	A	U	-	C	A	A	-	B	-	-	U	U	-	-	A	A	-	-	A	U*	-
Methyl Bromide	U	U	U	R	U	R	X	A	U	U	A	U	-	U	B	-	-	-	A	-	-	G	G	G	-	U	-	-
Methyl Butyl Ketone	-	U	-	-	U	U	U	-	-	-	U	A	-	U	U	-	U	-	U	-	-	A	A	-	-	-	-	-
Methyl Chloride	U	B	U	R	R	U	U	A	U	U	A	U	A	U	U	U	U	U	A	-	-	E	E	U	G	U	E	G
Methyl Chloroform	U	-	U	R	-	-	U	R	U	U	R	U	-	U	U	-	-	-	R	-	-	-	-	-	-	-	-	-
Methyl Dichloride	-	U	-	-	C	-	U	-	-	-	U	U	-	-	U	-	-	-	A	-	-	-	-	-	-	-	-	-
Methyl Ethyl Ketone	U	U	U	R	R	U	B	A	U	U	U	A	A	U	U	U	U	U	U	A	-	G	G	G	G	G	G	G
Methyl Isopropyl Ketone	-	-	-	-	A	-	-	A	U	-	-	C	-	U	U	-	C	-	U	-	-	A	A	-	-	A	-	A
Methyl Methacrylate	-	U	R	R	-	-	X	R	R	U	B	U	-	U	U	-	C	-	U	-	-	G	G	U	-	G	-	-
Methyl Pentanone	U	-	U	R	R	R	R	A	U	U	X	B	A	U	U	-	U	-	U	-	-	G	G	G	G	G	G	G
Methylene Chloride	U	B	U	R	U	U	B	A	U	U	B	X	A	U	U	U	-	U	B	-	R	G	G	G	E	E	G	G
Monochloroacetic Acid	-	U	-	-	U	U	-	A	-	-	B	C	B	A	U	-	-	-	C	-	-	A	A	-	A	U*	B	U*
Monoethanolamine	-	U	-	R	R	-	B	A	U	U	U	B	-	X	B	-	B	-	X	-	-	E	E	G	G	G	G	G
Motor Oil	C	B	A	R	R	U	U	A	R	R	B	U	A	B	A	-	-	A	R	A	-	G	G	G	-	-	G	G
Napthalene	U	X	U	R	R	U	R	A	U	U	A	U	A	U	U	R	U	C	A	A	-	E	E	G	G	G	G	G
Nitrobenzene	U	X	U	R	R	U	B	A	U	U	A	U	A	U	U	U	U	U	B	-	R	G	G	G	G	E	G	G
Nitromethane	U	A	U	R	U	-	R	A	R	R	A	B	A	U	U	-	U	B	U	-	-	G	G	G	-	G	-	-
Nitrophenol	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	-	-	-	-	-	-	G	G	-	-	G	-	G
Octane	-	-	-	R	-	R	R	R	U	U	R	U	-	R	R	-	-	-	R	-	-	-	G	G	-	G	G	G
Octyl Alcohol	A	A	B	-	A	-	-	-	-	-	-	B	-	B	B	-	B	-	B	-	-	A	A	-	C	A	-	A
Oleic Acid	X	A	A	R	R	U	B	A	R	R	A	B	B	X	B	R	U	C	B	A	-	E	E	G	G	G	S	G
Oxalic Acid 5%	R	U	R	R	U	R	R	R	R	R	R	R	-	R	U	-	-	-	R	-	-	U	G	U	G	G	S	G
Palmitic Acid 10%	A	A	A	R	R	R	B	A	R	R	A	B	-	U	A	R	U	B	A	-	-	-	G	-	-	G	G	G
Pentachlorophenol	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	-	-	-	R	-	-	-	-	E	-	-	-	-
Pentane	-	B	-	-	A	-	U	A	A	-	A	U	-	B	A	-	U	A	A	-	-	C	C	-	A	B	-	-
Petroleum	B	B	A	R	-	U	B	A	R	-	A	U	-	B	A	-	U	-	A	-	-	G	G	-	-	G	G	G
Phenol 10%	U	X	A	R	U	R	B	A	U	U	A	B	B	U	U	U	U	C	A	A	-	G	G	G	G	E	G	G
Phthalic Acid	B	C	X	R	R	-	A	A	U	U	A	A	-	A	U	-	B	-	A	-	-	G	E	S	G	G	G	G
Phthalic Anhydride	B	C	U	R	-	-	U	A	U	-	A	A	-	A	U	-	-	B	A	-	-	E	E	G	E	E	G	-
Picric Acid	X	A	U	R	U	U	A	A	U	U	A	A	-	A	X	-	B	-	A	-	R	G	G	U	G	E	U	U
Propyl Alcohol	X	A	A	R	U	R	A	A	R	R	A	A	A	A	A	-	A	A	A	A	-	E	E	G	E	G	G	G
Propylene	B	-	-	-	-	-	A	B	-	-	-	U	-	U	U	-	U	B	A	-	-	B	A	-	-	A	-	A
Propylene Glycol	B	B	X	R	R	R	A	A	U	U	A	A	-	C	A	-	A	-	A	A	-	G	G	G	G	G	G	G
Propylene Oxide	-	-	-	R	-	R	R	R	U	U	U	R	-	U	U	-	-	-	U	-	-	E	E	-	-	-	-	-
Pyridine	-	B	U	R	R	R	A	A	U	U	U	X	A	U	U	-	U	U	U	A	-	G	G	G	E	G	G	G
Sodium Acetate	B	B	A	R	R	R	A	A	R	R	A	A	A	B	B	-	U	-	U	A	-	G	G	U	G	E	G	G
Sodium Benzoate	A	-	A	R	R	R	A	A	R	R	A	A	-	A	B	-	-	B	A	-	-	-	-	-	G	G	-	E
Sodium Hypochlorite 20%	R	U	R	R	U	R	R	R	R	R	R	R	A	U	U	-	B	C	A	-	U	U	U	U	U	G	G	S
Stearic Acid	U	A	B	R	R	R	A	A	R	R	A	X	-	B	B	R	B	B	A	-	R	G	E	S	E	G	S	G

	Plastic									Elastopolymer							Metals											
	ABS	Acetal (Delrin)	CPVC	FEP	Nylon 6, 66	HDPE	Polypropylene	PTFE (Teflon®)	PVC Type I	PVC Type II	PVDF (Kynar)	EPDM	Kel-F	Neoprene	Nitrile Buna-N	Polyurethane	Silicone	Tygon®	Viton-A	Ceramic	Silica	304 Stainless	316 Stainless	Carbon Steel	Hastelloy-C	Aluminum	Brass	Copper
Styrene	-	A	U	-	A	U	-	A	U	-	-	U	-	U	U	-	U	-	B	-	-	A	A	-	U*	A	A	B
Tartaric Acid	-	B	A	-	B	-	A	A	A	-	B	B	A	A	A	-	A	B	A	A	-	C	C	-	B	B	U*	A
Tetrachloroacetic Acid	R	-	R	R	R	R	R	R	R	R	U	-	R	R	R	-	-	R	-	-	E	E	-	G	G	S	U	
Tetrachloroethane	-	A	X	R	R	-	C	A	U	U	A	U	A	U	U	-	U	-	A	-	R	E	E	E	E	G	-	S
Tetrachloroethylene	U	A	U	R	R	U	U	A	U	U	R	U	A	U	U	U	U	-	A	-	-	E	E	G	G	G	G	G
Tetrachlorophenol	-	-	-	-	-	-	R	R	-	-	R	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Tetraethyl Lead	U	-	R	R	-	U	R	R	R	R	R	U	-	-	U	-	-	-	R	-	-	G	G	G	-	G	G	-
Tetrahydrofuran	U	A	U	R	R	U	C	A	U	U	B	U	A	U	U	-	U	-	X	A	-	E	G	E	E	U	-	-
Toluene	U	X	U	R	R	U	C	A	U	U	A	U	B	U	X	U	U	U	C	A	-	E	E	E	E	E	E	E
Toxaphene-Xylene 10-90%	-	-	U	R	-	-	R	R	U	-	-	-	-	-	-	-	-	-	-	-	-	G	G	S	-	S	-	-
Trichloroacetic Acid	-	-	R	R	U	R	A	A	R	-	B	B	A	U	R	-	U	C	C	A	-	U	U	U	G	U	G	G
Trichlorobenzene	-	-	-	-	-	-	-	R	U	-	-	-	-	U	U	U	-	-	R	-	-	-	-	E	-	-	-	-
Trichloroethane	-	A	-	-	-	-	C	A	C	-	A	U	A	U	U	-	U	-	A	-	-	-	-	-	-	-	-	-
Trichloroethylene	U	U	U	R	R	U	C	A	U	U	B	U	A	U	U	U	U	-	X	A	-	G	G	G	E	E	G	G
Trichlorofluoromethane	-	-	-	-	-	-	-	-	U	-	-	-	-	U	U	-	-	-	-	-	-	-	G	-	-	G	-	-
Trichloropropane	U	A	-	-	-	-	-	A	-	-	-	-	A	A	U	-	-	U	A	-	-	A	A	-	A	U*	-	A
Triethanolamine	R	U	R	R	R	U	R	R	U	U	R	R	-	R	U	U	-	-	R	-	-	G	G	G	G	G	U	E
Triethylamine	U	U	A	R	R	-	U	A	R	R	A	A	A	A	C	-	-	A	X	B	-	G	G	-	-	-	-	-
Trimethylpropane	U	-	R	R	-	-	U	R	R	R	R	-	-	-	R	R	-	-	-	-	-	-	-	-	-	-	-	-
Turpentine	U	A	A	R	R	U	X	A	X	U	A	U	A	U	R	U	U	B	A	A	-	E	E	G	G	G	S	G
Vinyl Acetate	U	-	U	R	-	U	B	A	U	U	A	B	-	X	X	-	U	U	A	B	-	E	E	G	E	E	G	-
Vinyl Chloride	U	-	U	-	A	-	-	A	U	-	B	C	-	U	U	-	-	U	A	A	-	B	A	-	A	B	-	B
White Liquor (pulp mill)	X	U	R	R	R	-	R	R	R	R	R	R	-	R	R	-	-	-	R	-	-	G	G	S	G	G	-	-
White Water (paper mill)	R	B	-	-	R	-	R	-	R	-	-	-	-	A	-	-	-	-	A	-	-	A	A	-	-	-	-	-
Xylene	U	A	U	R	R	U	B	A	U	U	A	U	A	U	U	U	U	U	X	A	-	G	G	G	E	G	G	G

This table should only be used as a guide since it is difficult to duplicate operating conditions. To fully guarantee the suitability of a particular material, chemical resistance tests should be conducted under actual operating conditions.

No data was found on the following environmentally important chemicals:

Acenaphthene*	Chloromethylether	Fluoranthene*
Acenaphthalene*	Chlorophenylphenylether	Fluorene*
Acrolein	Chrysene*	Heptachlor**
Anthracene*	DDD**	Hexachlorobenzene
Benzidine	DDE**	Hexachlorobutadiene
Benzo(a)anthracene*	Dichlorobenzidine	Hexachlorocyclohexane
Benzo(b)fluoranthene*	Dichlorobromomethane	Indeno(1,2,3-c,d)pyrene*
Benzo(g,h,i)perylene*	Dichlorophenol	Isophorone
Benzo(a)pyrene*	Dichlorophenoxyacetic Acid	2-Methylnaphthalene
Bromophenylphenylether	Dichloropropane	Parachlorometa Cresol
Butylbenzylphthalate	Dichloropropylene	Phenanthrene*
Chlorodibromomethane	Dieldrin**	Phenylene-pyrene
Chloroethoxymethane	Dinitrophenol	Pyrene*
Chloroethylether	Diphenylhydrazine	Trichlorophenol
Chloroethylvinylether	Endosulfan	Trichlorophenoxyacetic Acid
Chloroisopropylether	Endrin**	

* Component of cresotene and coal tar. At room temperature and below, these compounds are solid in pure form.

** Pesticides